



Calibration and voltage measurement points:

- A** These points must be connected to GND during calibration
- B** VREF measurement point
- C** VCENTER measurement point
- D** VOFFSET data reading in these pins during calibration