

Light	MindWave State	Meaning
Off	Powered off	MindWave is turned off or has no battery
Double Blinking Blue	Pairing Mode	MindWave is ready to be paired to a device
Solid Red	Unpaired	MindWave needs to be paired to a device
Single Blinking Blue	Ready	MindWave is waiting for a paired device to connect
Solid Blue	Connected	MindWave is communicating with a paired device
Double Blinking Red	Low Battery	Need to replace the MindWave battery