




AUTOMATIC SWITCHING BETWEEN USB AND BATTERY




BATTERY SENSOR





USB FOR POWER AND DATA




BATTERIES




CONNECTION TO E-INK DISPLAY




ESP32




PIN LAYOUT



TEMPERATURE / HUMIDITY SENSOR



BUTTONS



ROTARY KNOB

