




## AUTOMATIC SWITCHING BETWEEN USB AND BATTERY




## BATTERY SENSOR




## USB FOR POWER AND DATA




## BATTERIES




## CONNECTION TO E-INK DISPLAY




## ROTARY KNOB




## PIN LAYOUT



## TEMPERATURE / HUMIDITY SENSOR



## ESP32



## BUTTONS

