




## AUTOMATIC SWITCHING BETWEEN USB AND BATTERY




## BATTERY SENSOR





## USB FOR POWER AND DATA




## BATTERIES




## CONNECTION TO E-INK DISPLAY




## ESP32




## PIN LAYOUT



## TEMPERATURE / HUMIDITY SENSOR



## BUTTONS



## ROTARY KNOB

