



Digit number 1 to 4
 Starting as DP1 shows the Hours (in tens)
 DP2 shows the hours from 1 to 9.
 DP3 shows the minutes in tens.
 DP4 shows the minutes from 1 to 9.



Digit 5 - shows the seconds in tens



Digit 6 - shows the seconds from 1 to 9

Sheet: /
 File: Atmega164.kicad_sch

Title:

Size: A4
 KiCad E.D.A. kicad (6.0.4)

Date:

Rev:

Id: 1/1