

MANUAL
SETUP GUIDE

boAt

plug into nirvana

• Whats In The Box

• Power On/Off

• Connection Mode

• LED Indicators

• Single Earbud Use

• Charging

• Functions

• Voice Assistant

• Factory Reset

Airdopes

Twin Wireless Ear-buds

Airdopes

Twin Wireless Ear-buds

Airdopes

Twin Wireless Ear-buds

Get ready to ride the waves of Nirvana with your all new boAt Airdopes 411v2. Please think of this manual as your map. Knowledge of Bluetooth and device connection is essential for the steering of this boAt. Therefore, we strongly advise that this manual is thoroughly read before beginning use, and referred to when in times of difficulty. We hope you're ready to Plug Into Nirvana.

In the box

1x boAt Airdopes 411v2

1x Charging Case

1x USB charging cable

2x pairs of additional earmuffs (S & M & L)

User Manual

Product Overview

1 MFB (Multi Function Button)

Indicator light

2

3 Charging contact point

4

5 How To Wear

6

4 Charging Case indicator

5

Power ON (First time user)

STEP 1 :
Take out the Earbuds out of the Charging Case.

STEP 2:
Please wait, Both Earbuds will automatically pair to each other. They will blink for 10 seconds & automatically connect to each other.

Wait for BLUE / RED LIGHTS on the left earbud and Right earbud stops blinking. This "BLUE / RED LIGHTS" means that it has gone into Connection Mode.

LED Indicators will not blink on the left Earbud

LED Indicators will blink on the Right Earbud

Right Earbuds is the Master Earbud, LED Indicators will only blink on the Right one during this stage.

NOTE: IF LEFT IS STILL BLINKING , DO FACTORY RESET LIKE IN PAGE 12

Connection Mode

STEP 3:
Turn on bluetooth on your device & then scan.

STEP 4:
Search for "boAt Airdopes 411v2" and pair accordingly. Congratulations, your earbuds are now connected successfully.

STEP 5:
You may now enjoy your music or any other entertainment form factor

"MFB" Stands for Multi Function Button.

NOTE: If the earbuds don't automatically Power On when taken out of charging case. STEP 1: Long Press MFB on Right earbud first, then Long Press MFB on left earbud. This will power on both the earbuds. Wait for BLUE / RED LIGHTS on the right earbud. This "BLUE / RED LIGHTS" means that it has gone into Scan Mode.

LED Indicators / Functionalities

2 Seconds

3 Seconds

5 Seconds

10 Seconds

Long Press MFB on either earbud for 2 Seconds to activate Voice Assistant. / Reject incoming Calls.

Manual Power ON:
Red Lights will Blink.

Manual Power OFF
Scan Mode:
Red/Blue Lights will Blink rapidly.

Factory Reset:
Purple Lights will Blink on both Earbuds.

Multi Function Button (MFB)

NOTE: Factory Reset will remove all device profiles saved on the Airdopes 411v2. Refer To Page 12.

Single Earbud Use

STEP 1 : At this stage your earbuds are in stereo mode & connected to your bluetooth device.

STEP 2 : Simply remove left earbud from your ear.

STEP 3 : And, place the left Earbud back into the Charging Case.

STEP 4 : Congratulations, you are now using mono/solo mode.

NOTE: Right Earbuds is the Master Earbud, Single Earbud use will only function on the right earbud.

NOTE: To switch to stereo mode, simply take out the left earbud out of the case & place it in your ear. The left earbud will automatically power on & pair with your right earbud hence enabling it for stereo usage

Charge The Earbuds

Put the boAt Airdopes 411v2 back into the charging case in their correct orientation.

A red light on the earbuds will indicate they are still being charged. This light will go off once the earbuds have been completely charged.

When both two earbuds are fully charged, the carrying case will switch off to save power.

Charge The Case

Warning: please do not charge the carrying case with "9V" or "12V" output. Otherwise, it may cause damage to the case.

To charge the case, plug in the USB cable and connect it to any USB port.

The 4 lights aligned vertically in the center of the charging case indicate the charge/battery status.

4 lights are illuminated for 60 seconds once the case has been completely charged

The earbuds can be charged a total of 4 times if the case is at full battery.

Basic Functions

Voice Assistant- Press the Multi Function Button for 2 seconds to activate voice assistant.

Answer/Hang up phone call- Tap the Multi Function Button once to answer any incoming call and once again to hang up once done talking.

Rejecting phone calls – Press and hold the Multi Function Button for 2 second to reject an incoming call.

Play/Pause – Tap the Multi Function Button to play/pause music at your convenience.

Next Track - When playing music, double click the right earbuds Multi Function Button to play the next track.

Previous Track - When playing music, double click the left earbuds Multi Function Button to play the previous track.

Volume up / Volume down- The volume cannot be changed from the earbuds, the volume will have to be adjusted via the connected device.

Please Note: The Volume can not be controlled via your Earbuds, and can only be adjusted through your device.

Voice Assistant

STEP 1 :
Long Press the MFB on either Left or Right Earbud for 2 Seconds to Activate Google / Siri Voice Assistant.

STEP 2 :
Google / Siri Assistant Screen will pop up & you may command at ease.

TIPS: You may try the following commands

"What is the weather?"

"Open Camera."

"Play my Playlist"

Smart Power Off

Your Airdopes 411v2 Earbuds will automatically Power On once taken out of the Charging Case. To Power Off follow below steps.

STEP 1 : After use, remove both left and right earbuds from your ear.

STEP 2 : Place & put back both the earbuds into the Charging Case.

STEP 3 : If LED is showing, it means it is charging.

Manual Power Off:

STEP 1 : If both earbuds are on, long Press either left or right earbuds for 5 Seconds to manually power off the Earbuds. Please note, this will power off both the earbuds.

STEP 2: Place them back into the charging case to charge the earbuds.

NOTE: Single Earbud Use will only function on the Right earbud.

Factory Reset/Solution:

Perform below tasks if you ever face any difficulties with your Airdopes 411v2.

Performing a Reset:

Take both earbuds out of the Charging case, this will power on your earbuds.

Now Manually Power Off the earbuds by Long Pressing MFB on both earbuds for 5 seconds, (RED Lights). DO NOT PUT EARBUDS IN CASE.

Now again, manually power on both the earbuds but don't release fingers. Continue this long press for 10 seconds till Purple LED Flashes on both earbuds. Then release fingers.

Both L & R earbuds will pair to each other, after 4 secs, R earbud will flash red/blue & L earbud will flash only Blue. Congratulations, "Factory Reset" is successfully performed.

Place back both the earbuds into charging case and refer to Page 4 to power on & page 5 to pair.

Common Problem With Solution

If one side working only:

If one side only working, then simply put back both earbuds in case or perform "Factory Reset".

If Earbuds not in scan mode:

If Earbuds not in Scan mode (No Red/Blue LED blink on left Earbuds) Simply put back both the earbuds in case and take out again or perform "Factory Reset".

Troubleshooting

Potential Problem	Solution
Right Earbud disconnects during phone call	Place the earbuds in the charging case and then try using them again. It will connect automatically.
Left & Right Earbuds are not pairing	Try re-setting the device.
About 20 seconds delay or easy disconnect for Right earbud	Power off, then switch on once more
Occasional disconnect and recover minutes later	Power off, then switch on once more
If there are other exceptions in use	Place the earbud's in the charging case and then try using them again. If this does not work, try re-setting the device

Specifications

Speaker Size
Sensitivity
Impedence
Response Range
Bluetooth Chip
Bluetooth Version
Waterproof Grade
Earbud Battery
Charging Base Batt.
Earbud Charge Time

6mm
94±3db
16Ω
20Hz-20KHz
AB1526P
Version 5.0
IPX 4
Li-Polymer Battery
2450mAh
500mAh
About 1.5 Hours

Charge Time For (Includes Charging Case)
Stand By Time (Includes Charging Case)
Music/Play/Talking Time:
A Fully-Charged Charging Case.

About 1.5 Hours
About 100 Hours
About 3.5 Hours (At 60% Volume)
Provides 3 Charge Cycles.

Cautions:

1. Please think of this manual as your map. Knowledge of Bluetooth and device connection is essential for the steering of this boAt. Therefore, we strongly advise that this manual is thoroughly read before beginning use, and referred to when in times of difficulty.

2. Please do not let the earbuds come into contact with sharp edges, uneven surfaces, and metal parts, in a manner that can lead to some form of permanent external or internal damage.

3. Please don't dismantle the product in any way, it can lead to a fire or electrical breakdown and even completely damage the product. As this is extremely unsafe, we ask that any maintenance of servicing of the headphones is done only through a qualified service provider/manufacturer.

4. Please do not remove the battery by yourself, this is a task meant to be managed by a service provider/manufacturer. Replacing the current battery with an ill-fitting set can result in a fire or electric hazard, therefore it is strongly advised against.

5. Please clean the earbuds with the utmost of care with only a damp soft cloth, if cleaning is required. Please do not use any oily volatile liquid. In addition, ensure that the Headsets are kept away from extremely hot or cold substances.

6. To avoid damage to your hearing, make sure that the volume on your music player is at an appropriate level when you are plugging into Nirvana. After wearing the earbuds, gradually turn up the volume until you reach a comfortable listening level. Exposure to any noise levels at or above 85 dB can gradually lead to a loss of hearing. Therefore, listening sessions that are at higher volumes should not be for too long. If you are planning to use the earbuds for extended periods of time, it is safer to keep the volume at a low level.

7. Any damage to the earbuds that is NOT a manufacturing issue will make the products warranty null and void. Please take the greatest care of your headphones to ensure that no such occurrences take place.

8. Do not use earbuds when it is unsafe to be wearing them, such as while operating a vehicle, crossing a street, or during any activity where full awareness of your surroundings is required. This is because it is dangerous to drive while wearing headphones as it decreases your ability to hear sounds like another car's horn or an emergency vehicle's sirens. Therefore, please avoid wearing your Headsets while driving.

Advisable: The earbuds will start at a 100% volume, and may need to be reduced when first switched on. This can be done using the volume control on your bluetooth

boAt

plug into nirvana

Airdopes

Twin Wireless Ear-buds