



## 台北南港展覽館2館

TAIPEI NANGANG EXHIBITION CENTER, HALL 2

### 四樓平面圖

4<sup>th</sup> Floor Plan

樓地板載重 Floor Load: 2,000kg/m<sup>2</sup>  
展場高度 Ceiling Height: 9m  
貨品出入口尺寸 Exhibit Entrance: 4.2×4.7m(H)  
R區 Area R  
Booth Size 3×3m, 451 Units (7,560m<sup>2</sup>)  
S區 Area S  
Booth Size 3×3m, 451 Units (7,560m<sup>2</sup>)  
全區 Area (R+S) = 902 Units

- 區域分界線  
Dotted Line (Indicates different areas)
- 柱 Pillar Size: 1.5×1.5m
- 消防栓 (含火警綜合盤) Fire Hydrant
- 火警綜合盤 Fire Alarm Panel
- 滅火器 Fire Extinguisher
- 水泥漆洗滌區 Painting equipment washing area
- 機房 Mech. Rom
- 自動體外心臟電擊去顫器 AED

- 火警盤、滅火器、消防栓、電箱、灑水開關、CO/CO2偵測器及避難方向指示燈皆不得封閉。  
Fire alarm panel, fire extinguisher, fire hydrant, power breaker, sprinkler switch, CO/CO2 sensor and all related signage in the hall should not be covered.
- 實際位置依現場為準。  
Location of devices and facilities should be confirmed on site.

- 本圖為標準攤位圖，僅供參考。  
This floor plan is for reference only, dimensions and composition are subject to change.
- 主辦單位所自行規劃之攤位圖，請先送外貿協會核定。  
Show organizer must submit planned floor map to TAITRA for prior consent.
- 四樓展場包柱位置及詳細尺寸，請另詳各展參展手冊或至台北南港展覽館官方網站 ([www.twtcnangang2.com.tw](http://www.twtcnangang2.com.tw)) 「表單下載」處，詳閱「4樓攤位臨柱示意圖」。  
For locations and specifications of pillars on each floor, refer to the show manual or visit [www.twtcnangang2.com.tw](http://www.twtcnangang2.com.tw) to download the 1st floor booths and pillars location map.
- 行李寄放室由展覽單位自行規劃提供。  
Luggage storage is only provided per arrangement by show organizer.