

BATTERY

POT

ON_OFF_SW

SPEAKER

DFMINI PLAYER

R6

R7

GYROSCOPE

B11

R10

STM32F103C8T

R1

R2

R3

R4

R5

LCD

WIFI

R9

R8