


## ■ GPRS network mode

Long press the "M" key for 2 seconds to enter the "Configure the Network" mode, in this mode, press "-" to set to "GPRS Network Mode" (please insert the SIM card to use). After the setting is complete, restart the speaker and the network mode setting is successful.

## ■ WIFI network mode

1. Install amlink.apk, and accept all the Permission requirements of this APK.
2. Long press the "M" key for 2 seconds to enter the "Configure Network Mode", in this mode, press "+" to set to "WIFI Network Mode" and enter WIFI configuration.
3. Run amlink.apk, select the WIFI AP(only support 2.4GHz, not support 5GHz) to link, input the correct password of the connected WIFI of the mobile phone to configure
4. Wait for the prompt "Configuration setup successful" to indicate the completion of the speaker WIFI configuration.



5. The possible reasons of WIFI connect failure:

- 1) Please check if the WIFI you want to connect is 2.4GHz, not 5GHz.
- 2) Enter your phone WIFI setting page, select KM\_AP to forget password or ignore, then try to Steps 2-4 again.