




## 10




# RESET




# USB\_UART/UART1




## JTAG




# LCD/OLED




# BOOT




# SRAM




## MCU




RS232




RS485




CAN&USB




EEPROM




JOYPAD




LED




KEY




ADC&DAC




BEEP




WIRELESS




SD CARD&INTERNET




FLASH




TEMP&HUMI SENSOR




REMOTE




RES- ADJ




STEPPING MOTOR




OLED&CAMERA




DC POWER IN




ON BOARD POWER SOURCE




3.3V&POWER SWITCH




USB USART&USB POWER



RELAY



## AUDIO AMP



## PWM DAC/AUDIO

