



Allen Bradley Ports

- 0/1 - GS1 – Field Reset Lights
- 2/3 – GS2 – NC
- 4/5 – GS3 – NC
- 6/7 – GS4 – Charge Station Lights
- 8/9 – GS5 – Charge Station Sensors
- 10/11 – Station 3 E-stop and Light
- 12/13 – Station 2 E-stop and Light
- 14/15 – Station 1 E-stop and Light

← SCORING TABLE →

 **SOLIDWORKS**
 Modeling Solutions Partner



Use the on-board switch to connect to Team Signs and any other devices.

Connect ethernet trunk to scoring table to UPLINK port on side of case.

Route cable for each driver station to Station 1, 2 & 3 ports on top of case.

The case should be off set to the left side of station 2.

