







Setting Up the Flow-Voyager Application for use

1. Install the Flow-Voyager Application to the IED from Catalog







2. Run “IE Flow-creator” application by double clicking it logging in with user credentials
3. Import the “triggerFlow.json ” file to the Flow-creator application




4. The imported flow looks as follow



5. Double click the “Login-IEM” node and enter the user credentials for the IEM, including iemUrl, username, password



6. Double click the “Request-IED-node” and enter the request “URL ” in the format “*http://<ip-address-of-ied >:33080/api/v2/deploy/cloud*”
7. *Click done after inputting the user-credentials and the URL to update the flow*



8. After the user had developed new flows logic and function and wish to deploy the flow as an application
9. Click on “Deploy ” to update all the changes in the “IE flow creator” and then click on “trigger” node to automate new instance deployment by sending an API request to the “Flow-Voyager” application.

