

Customization by Elehobica:
Add R20, R21 and switch lines
Replace R5, R11 (18K) with 10K/B VR (to adjust L/R balance)

Copyright (c) 2023 Elehobica. All rights reserved.

Elehobica

Sheet: /Sheet_TA7668BP/

File: Sheet_TA7668BP.kicad_sch

Title: TA7668BP CXA1332M board (customized by Elehobica)


Size: A4

Date: 2023-10-18

Rev: 1.0.0

KiCad E.D.A. eeschema 7.0.7

Id: 2/4



Copyright (c) 2023 Elehobica. All rights reserved.

Elehobica

Sheet: /Sheet_CXA1332M/

File: Sheet_CXA1332M.kicad_sch

Title: TA7668BP CXA1332M board (customized by Elehobica)

Size: A4


Date: 2023-10-18

Rev: 1.0.0

KiCad E.D.A. eeschema 7.0.7

Id: 3/4

Customization by Elehobica:
Add whole circuits in this sheet



NR_CTRL0 = L, NR_CTRL1 = L: Dolby B
NR_CTRL0 = H, NR_CTRL1 = L: Dolby C
NR_CTRL0 = X, NR_CTRL1 = H: NR OFF
EQ_CTRL = L: EQ 120us
EQ_CTRL = H: EQ 70us

Copyright (c) 2023 Elehobica. All rights reserved.

Elehobica

Sheet: /Sheet_MCU_CTRL/

File: Sheet_MCU_CTRL.kicad_sch

Title: TA7668BP CXA1332M board (customized by Elehobica)

Size: A4

Date: 2023-10-18

Rev: 1.0.0

KiCad E.D.A. eeschema 7.0.7

Id: 4/4