

Boombbox Fix



DECK - PLAY BACK ONLY

TAPE DIRECTION

DECK - PLAY BACK - RECORDING

TAPE DIRECTION

0 50 100

0 50 100

DUAL DECK STEREO RADIO CASSETTE RECORDER

CONTINUOUS PLAY A → B - HIGH SPEED DUBBING

MICROPHONE

565 · 500 · 400 · 300 · 230 · 190 METERS CHAN 2 · 10 · 20 · 30 · 40 · 50 · 60 · 70 CHANNELS

AM KHz

530 650 850 1200 1600 KHz

MHz

88 92 96 100 104 108 MHz FM

MODE INDICATION

POWER FM STEREO DUBBING

VOLUME

MIN 0 1 2 3 4 5 6 MAX

5 BAND GRAPHIC EQUALIZER

RIGHT +10 0 -10
100Hz 300Hz 1kHz 4kHz 10kHz
LEFT


TAPE COUNTER

DB300 DUAL DECK STEREO RADIO CASSETTE RECORDER

MAGNAVOX







Imagine
Crafts

3139
110-90141
8Ω 4W
SGP 891010

3139
110-90131
4Ω 8W
SGP 891012

3139
110-90141
8Ω 4W
SGP 891010

CAUTION FOR CONTINUED PROTECTION
AGAINST FIRE HAZARD REPLACEMENT ONLY
WITH SAME TYPE T 2A, 125V
MIN. FUSE PLACEMENT TO QUALITY
SERVICE PERSONNEL



