


origin\_distance

**/etc/fabscanpi/default.config.json:** **"calibration": { "pattern": {**  
**square\_Size:** 11 [11 x 11 mm] | **rows:** 8 | **columns:** 6  
**origin\_distance:** 16.0 [mm] (+ your socket height) or you messure direct from Turntable. }



**Shield Size:** 121 x 130 mm