




Good Voice



GV-SA0361

Good Voice Personal Sound Amplifier
Instructions for Use



Before you begin	2
Contents	3
Controller overview	4
Bluetooth earphone	5
Start using	6
Work with your mobile phone	8
Use in everyday life	10
Charging the Battery	12
Specification	14
Manufacturer	15
Warranty card	16

※ **WARNING :** If you are younger than 18, do not use this. You should go to a doctor, preferably an ear-nose-throat doctor (an ENT), because your condition needs specialized care.



Before you begin

1. Thank you for purchasing Good Voice. Read this manual before use.
2. Do not repair, disassemble, or modify the product yourself. This will void the warranty. Contact the dealer if you have questions.
3. Keep this Instructions for Use with you.
4. Please keep the device away from the source of electromagnetic or radiation, as these might interfere with the operation of device.
5. Do not use corrosive or abrasive cleaners.
6. This product is not waterproof. Do not splash water or immerse it.
7. Do not apply excessive pressure.
8. Do not expose to direct sunlight, fire, or extreme temperatures.
9. Avoid strong vibrations or impacts.
10. Check the volume before using. Adjust to a comfortable level. If you hear a sharp feedback sound, lower the volume or stop using.
11. Keep out of reach of children to prevent accidents.
12. The product charges fully in 3 hours. Unplug the charging cable when done. Do not overcharge.
13. Only the manufacturer should replace the lithium battery. Improper replacement can cause an explosion. Use the same or equivalent type. Dispose of used batteries properly.
14. Battery life varies by usage and production time.
15. Software updates may change product features. Refer to the product for actual use. This manual is for reference only.

Contents

If any contents are damaged or missing, please contact your distributor immediately.



▲Controller



▲Bluetooth Earphones



▲Instruction for use
(including Warranty Card)




▲External Microphone




▲charging cable
(Type-C + Type-C)

Controller Overview



Bluetooth Earphone



※The included Bluetooth earphones is exclusively designed for pairing with the controller.

Start Using



1


Turn on the Controller

- ▲ Press power buttons to turn on the controller.
- ▲ Press power buttons for 3 sec to turn off.

2

Turn on the Bluetooth earphones

- ▲ Press the power button of Bluetooth earphones for 3 seconds until the blue light flashes.
- ▲ Press for 3 seconds to turn off.



The earphones will be automatically paired with the controller

- Searching: The blue light (of the Bluetooth earphones) flashes twice at each interval.
- Connected: The blue light flashes once at each interval. The indicator will be lighting.



3

Put on the Bluetooth earphones

▲ Place the controll panel on your left side.



4

Adjust the Volume



- ▲ Press “+” to volume up
- ▲ Press “-” to volume down

※ Audio feedback can occur at any time, please keep the distance from the Controller to the earphones.

Working with Mobile Phone



Connecting with Bluetooth

- ▲ Turn on Bluetooth on your phone.
- ▲ Choose “OK GoodVoice” in Bluetooth setting of your phone.
- ▲ Press  on controller for 5 seconds until  flashes in the middle of screen.

※ When you turn off your “OK Good Voice” or mobile phone, they will no longer be connected. To connect them again, turn on your “OK Good Voice” and mobile phone. Your “OK Good Voice” will then automatically re-connect to your mobile phone.

※ If Bluetooth is disconnected from your phone, follow above steps to re-connect.






Answering Phone Calls



iOS


- ▲ Answer directly from device: Press  on the controller.
- ▲ Answer from your iPhone: Swipe right --> press the speaker --> choose "OK Good Voice".

Android

- ▲ Swipe your phone to answer it. (Do not answer the phone from device directly.)





Enjoying the audio playing on your phone


- ▲ Press  to listen to music or video playing on your phone. Press the button again to return to regular mode.

Use in everyday life

When You are in a Noisy Environment

Press  for the noise-reduction mode. It will reduce the ambient noise.

Press  again to increase ultimate noise cancellation.

Press  again to return to regular mode.



Daily Life Scenarios

Sling for easy wearing.

Using the external microphone or placing the controller near the sound source will help you hear better.



When You are in a Meeting

Put the controller on the center of conference room table, which makes following and participating in conversations easier.





When You are Watching TV

Put the controller near the TV for better hearing.



Charging the Battery




Low Battery  displays and flashes on the screen

Charging The battery icon shows the battery level and flashes

Charging Completed Battery icon stops flashing

Charge with
a Type-C cable

※ Prepare a portable charger with you when you are going out to make sure you can recharge your “OK Good Voice” in time.





Specification

Controller	Bluetooth Version:4.0 Bluetooth Protocol : A2DP, AVRCP, HFP, HSP Operating Range:10M Bluetooth power : CLASS 2 Bandwidth of Bluetooth : 2.40 — 2.480GHz Battery capacity : 1400mAh/3.7V Use of Time : ~ 10 hours, rechargeable Charge of Time : 2~2.5 hours Charging voltage/current : 5V/400mA~650mA (Max) External Microphone Port: * 1
------------	--

Bluetooth Earphone	Bluetooth Version:5.0 Bluetooth Protocol : A2DP, AVRCP, HFP, HSP Bluetooth power : CLASS 2 Bandwidth of Bluetooth : 2.40 — 2.480GHz Battery capacity : 280mAh/3.7V Use of Time : 8 hours, rechargeable
--------------------	---

Manufacturer

OK Biotech Co., Ltd.

Address: No. 91, Sec. 2, Gongdao 5th Rd.,
Hsinchu City 30070, Taiwan (ROC)

Website: www.okbiotech.com

Tel: +886-3-5160258

Made in Taiwan

FCC Warning Statement



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warranty Card

Thank you for choosing "OK GoodVoice". This warranty applies for the period of 12 months from the date of purchase. Please keep the warranty card properly with you.

Name: _____

Address: _____

Phone: _____

E-mail: _____

Production Lot
Number: _____

Date of

Purchase: _____

Purchased

from (Dealer's
Name): _____

1. In the period of warranty, we warrant your new "Good Voice" against defects in material and workmanship. Repair or replacement of your "Good Voice" is subject to the restrictions and conditions described in the following paragraphs.
 - Damage resulting from misuse, abuse, accident, modification, and unsuitable physical or operating environment, natural disasters.
 - Loss, careless handling or tampering, defects or damage by unauthorized service.
2. This limited warranty does not cover accessories such as charging cable, external microphone.
3. This limited warranty is not transferable and applies only to the original purchaser.
4. Altering or removing identification label on the controller might affect your Warranty.
5. The repair or replacement cannot be performed under the warranty if you refuse to provide your information, or without the dealer stamp on the warranty card.

Dealer Stamp

10-81-0310-0003 V1-APR24

