



- Lidar PWM is connected on TIMER 1
- Leds are connected on TIMER 2
- Status led is on the Nucleo
- PG10 is unused because is the reset pin



**Evolutek<< & Coffee Machine**

Sheet:  
File: V4.kicad\_sch

**Title: Carte MDB**

Size: A4	Date: 2024-01-06
----------	------------------

Size: 771	Date:
KiCad E.D.A.	kicad 7.0.6

Rev: V4.4

Id: 1/1