

2. RS-232 Command

W5000 RS232 Command Set -- X series			
Code	Function	ACK	Note
X000X	RS232 Communication Test	X000X RS232 OK X0_0X	
X001X	Power ON	X0_01X	
X002X	Power OFF	X002XX0_2X	
X003X	Menu	X003XX0_3X	
X004X	Enter	X004XX0_4X	
X005X	Exit	X005XX0_5X	
X006X	Up	X006XX0_6X	
X007X	Down	X007XX0_7X	
X008X	Left	X008XX0_8X	
X009X	Right	X009XX0_9X	
X041X	Picture Mode -- Cinema Mode	X041XX0_41X	
X044X	Picture Mode -- Dynamic Mode	X044XX0_44X	
X045X	Picture Mode -- Standard Mode	X045XX0_45X	
X046X	Picture Mode -- User 1 Mode	X046XX0_46X	
X047X	Picture Mode -- User 2 Mode	X047XX0_47X	
X048X	Picture Mode -- User 3 Mode	X048XX0_48X	
X049X	Reset All Settings(User OSD)	X049XX0_49X	
X091X	Lamp Power -- Whisper Mode	X091XX0_91X	
X092X	Lamp Power -- Normal Mode	X092XX0_92X	
X093X	Auto Source Searching OFF	X093XX0_93X	
X099X	Reset All Settings and Timers(User OSD)	X099XX0_99X	
X100X	Black Level -- 0 IRE	X100XX0_100X	
X101X	Black Level -- 7.5 IRE	X101XX0_101X	
X112X	Color Temperature -- Lamp Native	X112XX0_112X	
X113X	Color Temperature -- Warm	X113XX0_113X	
X114X	Color Temperature -- Normal	X114XX0_114X	
X115X	Color Temperature -- Cool	X115XX0_115X	
X116X	Color Temperature -- User 1	X116XX0_116X	
X117X	Color Temperature -- User 2	X117XX0_117X	
X118X	Color Temperature -- User 3	X118XX0_118X	
X121X	Language -- English	X121XX0_121X	
X122X	Language -- French	X122XX0_122X	
X123X	Language -- German	X123XX0_123X	
X124X	Language -- Italian	X124XX0_124X	
X125X	Language -- Spanish	X125XX0_125X	
X126X	Language -- Russian	X126XX0_126X	
X127X	Language -- Traditional Chinese	X127XX0_127X	
X128X	Language -- Simplified Chinese	X128XX0_128X	
X131X	Input Source -- Video	X131XX0_131X	
X132X	Input Source -- S-Video	X132XX0_132X	
X133X	Input Source -- RGBHD Source	X133XX0_133X	
X135X	Input Source -- Component 1	X135XX0_135X	
X139X	Input Source -- HDMI 1	X139XX0_139X	
X140X	Input Source -- Component 2	X140XX0_140X	
X149X	Input Source -- HDMI 2	X149XX0_149X	
X151X	Reset Lamp Timer(User)	X151XX0_151X	
X154X	Auto Function for PC Timings	X154XX0_154X	

X400X	Enable Dynamic Black Function	X400XX0_400X	
X401X	Disable Dynamic Black Function	X401XX0_401X	
X997X	Print Message -- FW Revision	X997XX0_997X	

W5000 RS232 Command Set -- Z series Write				
Code	Function	ACK	Note 1	Note 2
Z011W(data)Z	Picture Basic OSD -- Brightness	Z011W(data)ZZ0_11(data)Z	data range: +0000 ~ +0100	
Z012W(data)Z	Picture Basic OSD -- Contrast	Z012W(data)ZZ0_12(data)Z	data range: +0000 ~ +0100	
Z014W(data)Z	Picture Basic OSD -- Color	Z014W(data)ZZ0_14(data)Z	data range: +0000 ~ +0100	
Z015W(data)Z	Picture Basic OSD -- Tint	Z015W(data)ZZ0_15(data)Z	data range: -0020 ~ +0020	
Z016W(data)Z	Picture Basic OSD -- Sharpness	Z016W(data)ZZ0_16(data)Z	data range: +0000 ~ +0008	
Z024W(data)Z	Vertical Keystone	Z024W(data)ZZ0_24(data)Z	data range: -0035 ~ +0035	
Z025W(data)Z	Horizontal Keystone	Z025W(data)ZZ0_25(data)Z	data range: -0035 ~ +0035	
Z026W(data)Z	Vertical Position	Z026W(data)ZZ0_26(data)Z	data range: by timings	
Z027W(data)Z	Horizontal Position	Z027W(data)ZZ0_27(data)Z	data range: -0015 ~ +0015	
Z008W+0000Z	Language -- English	Z008W+0000ZZ0_8+0000Z		
Z008W+0001Z	Language -- French	Z008W+0001ZZ0_8+0001Z		
Z008W+0002Z	Language -- German	Z008W+0002ZZ0_8+0002Z		
Z008W+0003Z	Language -- Italian	Z008W+0003ZZ0_8+0003Z		
Z008W+0004Z	Language -- Spanish	Z008W+0004ZZ0_8+0004Z		
Z008W+0005Z	Language -- Russian	Z008W+0005ZZ0_8+0005Z		
Z008W+0006Z	Language -- Traditional Chinese	Z008W+0006ZZ0_8+0006Z		
Z008W+0007Z	Language -- Simplified Chinese	Z008W+0007ZZ0_8+0007Z		
Z008W+0008Z	Language -- Japanese	Z008W+0008ZZ0_8+0008Z		
Z008W+0009Z	Language -- Korean	Z008W+0009ZZ0_8+0009Z		
Z008W+0010Z	Language -- Swedish	Z008W+0010ZZ0_8+0010Z		
Z008W+0011Z	Language -- Dutch	Z008W+0011ZZ0_8+0011Z		
Z008W+0012Z	Language -- Turkish	Z008W+0012ZZ0_8+0012Z		
Z008W+0013Z	Language -- Czech	Z008W+0013ZZ0_8+0013Z		
Z008W+0014Z	Language -- Portuguese	Z008W+0014ZZ0_8+0014Z		
Z008W+0015Z	Language -- Thai	Z008W+0015ZZ0_8+0015Z		
Z008W+0016Z	Language -- Polish	Z008W+0016ZZ0_8+0016Z		
Z009W+0000Z	Aspect Ratio -- Anamorphic	Z009W+0000ZZ0_9+0000Z		
Z009W+0001Z	Aspect Ratio -- 4:3	Z009W+0001ZZ0_9+0001Z		

Z009W+0002Z	Aspect Ratio -- Letter Box	Z009W+0002ZZ0_9+0002Z		
Z009W+0003Z	Aspect Ratio -- Wide	Z009W+0003ZZ0_9+0003Z		
Z009W+0004Z	Aspect Ratio -- Real	Z009W+0004ZZ0_9+0004Z		
Z010W+0000Z	Picture Mode -- Cinema Mode	Z010W+0000ZZ0_10+0000Z		
Z010W+0001Z	Picture Mode -- Dynamic Mode	Z010W+0001ZZ0_10+0001Z		
Z010W+0002Z	Picture Mode -- Standard Mode	Z010W+0002ZZ0_10+0002Z		
Z010W+0003Z	Picture Mode -- User 1 Mode	Z010W+0003ZZ0_10+0003Z		
Z010W+0004Z	Picture Mode -- User 2 Mode	Z010W+0004ZZ0_10+0004Z		
Z010W+0005Z	Picture Mode -- User 3 Mode	Z010W+0005ZZ0_10+0005Z		
Z017W+0000Z	Color Temperture -- Lamp Native	Z017W+0000ZZ0_17+0000Z		
Z017W+0001Z	Color Temperture -- Warm	Z017W+0001ZZ0_17+0001Z		
Z017W+0002Z	Color Temperture -- Normal	Z017W+0002ZZ0_17+0002Z		
Z017W+0003Z	Color Temperture -- Cool	Z017W+0003ZZ0_17+0003Z		
Z017W+0004Z	Color Temperture -- User 1	Z017W+0004ZZ0_17+0004Z		
Z017W+0005Z	Color Temperture -- User 2	Z017W+0005ZZ0_17+0005Z		
Z017W+0006Z	Color Temperture -- User 3	Z017W+0006ZZ0_17+0006Z		
Z022W+0000Z	Input Source -- HDMI 1	Z022W+0000ZZ0_22+0000Z		
Z022W+0001Z	Input Source -- HDMI 2	Z022W+0000ZZ0_22+0001Z		
Z022W+0002Z	Input Source -- Video	Z022W+0002ZZ0_22+0002Z		
Z022W+0003Z	Input Source -- S-Video	Z022W+0003ZZ0_22+0003Z		
Z022W+0004Z	Input Source -- Component 1	Z022W+0004ZZ0_22+0004Z		
Z022W+0005Z	Input Source -- Component 2	Z022W+0005ZZ0_22+0005Z		
Z022W+0006Z	Input Source -- RGBHD	Z022W+0006ZZ0_22+0006Z		
Z023W+0000Z	Projector Position -- Floor Front	Z023W+0000ZZ0_23+0000Z		
Z023W+0001Z	Projector Position -- Ceiling Front	Z023W+0001ZZ0_23+0001Z		
Z023W+0002Z	Projector Position -- Floor Rear	Z023W+0002ZZ0_23+0002Z		
Z023W+0003Z	Projector Position -- Cerling Rear	Z023W+0003ZZ0_23+0003Z		
Z030W+0000Z	Auto Source Searching OFF	Z030W+0000ZZ0_30+0000Z		
Z030W+0001Z	Auto Source Searching ON	Z030W+0001ZZ0_30+0001Z		
Z031W+0000Z	Sleep Timer -- Disable	Z031W+0000ZZ0_31+0000Z		
Z031W+0001Z	Sleep Timer -- 30 mins	Z031W+0001ZZ0_31+0001Z		
Z031W+0002Z	Sleep Timer -- 60 mins	Z031W+0002ZZ0_31+0002Z		

Servicon AS terje.jorgensen 2009/04/29	Servicon AS terje.jorgensen 2009/04/29	Servicon AS terje.jorgensen 2009/04/29	Servicon AS terje.jorgensen 2009/04/29	Servi terje.j 2009
Z031W+0003Z	Sleep Timer -- 90 mins	Z031W+0003ZZ0_31+0003Z		
Z031W+0004Z	Sleep Timer -- 120 mins	Z031W+0004ZZ0_31+0004Z		
Z031W+0005Z	Sleep Timer -- 150 mins	Z031W+0005ZZ0_31+0005Z		
Z031W+0006Z	Sleep Timer -- 180 mins	Z031W+0006ZZ0_31+0006Z		

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servi
terje.j
2009

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servi
terje.j
2009

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servi
terje.j
2009

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servi
terje.j
2009

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servicon AS
terje.jorgensen
2009/04/29

Servi
terje.j
2009