





机器关机断电，然后打开机箱找到PWRD\_EN跳线，如下图所示。  
将跳线帽接到4-6针，然后通过启动机器，等待BIOS自检通过后再关机断电，恢复跳线帽位置，通电重启即可。

| System Board Jumper Settings |   |   |
|------------------------------|---|---|
| Jumper                       | Setting   | Description   |
| PWRD_EN                      |  2 4 6 (default) | The password reset feature is enabled (pins 2–4). BIOS local access is unlocked at the next AC power cycle. |
|                              |  2 4 6           | The password reset feature is disabled (pins 4–6).  |
| NVRAM_CLR                    |  1 3 5 (default) | The configuration settings are retained at the next system boot (pins 3–5).                                 |
|                              |  1 3 5           | The configuration settings are cleared at system boot (pins 1–3).   |

