

# RADIO CONTROL WEB-BLASTING TARANTULA

AAAx4


NOT INCLUDED

9Vx1

NOT INCLUDED

## How to Play


### START TO PLAY:



- 1) Push the ON/OFF switch to the "ON" position of the spider.
- 2) Push both the Levers forward for forward motion.

- 3) Pull both the Levers backward for reverse motion.
- 4) Release both Levers, the Tarantula will stop.


### 360 DEGREE SPINS:



- 5) Push the Right Lever forward while pulling the Left Lever backward at the same time.
- 6) Push the Left Lever forward while pulling the Right Lever backward at the same time.
- 7) Push only the Left Lever forward to turn Right.
- 8) Push only the Right Lever forward to turn Left.
- 9) Pull only the Right Lever backward to turn Right.
- 10) Pull only the Left Lever backward to turn Left.


# Battery Installation (FOR MAXIMUM PERFORMANCE, ONLY USE ALKALINE BATTERIES)

## TRANSMITTER:



- 1) Slide the battery cover and install a 9'V' (6LR61) battery by matching (+) and (-) sign as indicated in the battery compartment.
- 2) Replace the battery cover.

## SPIDER:



- 1) Make sure the ON/OFF switch of the Web Blasting Tarantula is at the OFF position.
- 2) Unscrew to open the battery cover.
- 3) Install (4) AAA (LR03) batteries by matching (+) and (-) sign as indicated in the battery compartment.
- 4) Replace the battery cover and screw tightly.

### PERFORMANCE TIPS:

- Web will shoot out randomly and retracts after 3 seconds.
- Don't go through water.
- Use fresh alkaline batteries.
- Make sure ON/OFF switch on your spider is OFF when not in use.
- Don't bend antenna.
- Electrical, CB interference, mobile phones, air conditioning, elevators and steel girders in buildings may affect the operation of your spider.
- Don't leave the spider or transmitter near sources of heat or under direct sunlight for long periods of time.

### BATTERY TIPS:

- For maximum performance use Alkaline batteries.
- Batteries should be installed and replaced by adults.
- Do not dispose of batteries in fire, battery may explode or leak.
- Only batteries of the same type should be used.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (Carbon Zinc) or rechargeable batteries.
- Insert batteries according to polarity, remove dead batteries and dispose of properly according to local laws.
- Do not short circuit supply terminals.
- Do not charge non-rechargeable batteries.

**WARNING:** CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

**NOTE:** THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS B DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE IN A RESIDENTIAL INSTALLATION. THIS EQUIPMENT GENERATES, USES AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTIONS, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS. HOWEVER, THERE IS NO GUARANTEE THAT INTERFERENCE WILL NOT OCCUR IN A PARTICULAR INSTALLATION. IF THIS EQUIPMENT DOES CAUSE HARMFUL INTERFERENCE TO RADIO OR TELEVISION RECEPTION, WHICH CAN BE DETERMINED BY TURNING THE EQUIPMENT OFF AND ON, THE USER IS ENCOURAGED TO TRY TO CORRECT THE INTERFERENCE BY ONE OR MORE OF THE FOLLOWING MEASURES:

- REORIENT OR RELOCATE THE RECEIVING ANTENNA.
- INCREASE THE SEPARATION BETWEEN THE EQUIPMENT AND RECEIVER.
- CONNECT THE EQUIPMENT INTO AN OUTLET ON A CIRCUIT DIFFERENT FROM THAT TO WHICH THE RECEIVER IS CONNECTED.
- CONSULT THE DEALER OR AN EXPERIENCED RADIO/TV TECHNICIAN FOR HELP.

### FCC NOTE:

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION. THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

THE ANTENNA PROVIDED IS A UNIQUE ANTENNA. INSTALLATION OF UNAUTHORIZED ANTENNA TO THIS EQUIPMENT COULD HINDER THE USER'S ABILITY TO OPERATE THE EQUIPMENT.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD HINDER THE USER'S ABILITY TO TO OPERATE THE EQUIPMENT.

**ToysRUs**

CONFORMS TO THE SAFETY  
REQUIREMENTS OF ASTM F963.

Contents and colors may vary.

Patent Pending - Fantasma Toys, Inc.

### CAUTION:

Remove all twist-ties and plastic  
loops before giving toy to child.

Do not mix old and new batteries.  
Do not mix alkaline, standard (carbon-zinc),  
or rechargeable batteries.

© 2014 DISCOVERY COMMUNICATIONS, LLC.  
ANIMAL PLANET AND THE ANIMAL PLANET LOGO  
ARE TRADEMARKS OF (ET LE LOGO ANIMAL  
PLANET SONT DES MARQUES DÉPOSÉES DE/Y EL  
LOGO DE THE ANIMAL PLANET SON. MARCAS  
REGISTRADAS DE) DISCOVERY COMMUNICATIONS,  
LLC, USED UNDER LICENSE (UTILISÉES SOUS  
LICENCE/UTILIZADO BAJO LICENCIA). ALL RIGHTS  
RESERVED (TOUS DROITS RÉSERVÉS/TODOS LOS  
DERECHOS RESERVADOS).

ANIMALPLANET.COM ANIMALPLANET.CA

© 2014 GEOFFREY, LLC, A SUBSIDIARY OF (UNE FILIALE DE/UNA  
SUBSIDIARIA DE) TOYS"R"US, LLC. MADE IN CHINA (FABRIQUÉ EN  
CHINE/FABRICADO EN CHINA), DISTRIBUTED IN THE UNITED STATES  
BY (DISTRIBUÉ AUX ÉTATS-UNIS PAR/DISTRIBUIDO EN LOS ESTADOS  
UNIDOS POR) TOYS"R"US, INC., WAYNE, NJ 07470. IMPORTED BY  
(IMPORTÉ PAR/IMPORTADO POR) TOYS"R"US (CANADA) LTD. (LTÉE),  
2777 LANGSTAFF ROAD, CONCORD, ON L4K 4M5. DISTRIBUTED IN  
AUSTRALIA BY (DISTRIBUÉ EN AUSTRALIE PAR/DISTRIBUIDO EN  
AUSTRALIA POR) TOYS"R"US (AUSTRALIA (AUSTRALIE)) PTY  
LTD.(LTÉE), REGENTS PARK NSW 2143.

www.toysrus.com www.toysrus.ca