

# Android Gamepad Use Manual

## 1. Introduce

The Android Gamepad has four modes: Gamepad mode, Keyboard mode, APP mode, Icade mode. Different modes support different games. Among these modes, Gamepad mode, Keyboard mode, APP mode support android phone, tablet and set top box. The Icade mode only supports IOS devices. The gamepad uses HID protocol data transmission.

## 2. Device connecting

Please use combination keys to enter the pairing mode. The following shows the different bluetooth indicators' light in different mode.

Mode	Gamepad Mode	Keyboard Mode	APP Mode	Icade Mode
Butons combine	□+Home	X+Home	△+Home	○+Home
Indicator light	①	②	③	①②

➤ **Gamepad mode:** When the gamepad is turned off, press Square button and Home button at the same time, then the three lights flash quickly. Open the bluetooth function of your phone and search the bluetooth device and click pairing to enter Gamepad mode. Now you can enter the game and play.(Some games request key settings. Please go to the game options to set the keys.)

➤ **Keyboard mode:** When the gamepad is turned off, press X button and Home button at the same time, then the three lights flash quickly. Open the bluetooth function of your phone and search the bluetooth device and click pairing to enter Keyboard mode. Now you can enter the game and play.(Some games request key settings. Please go to the game options to set the keys.)

➤ **APP mode**(Note: APP mode is devided into two modes. Key mode and Touch mode.)

**Touch mode:**(Note:This mode requires Root privileges. You can't use this mode without Root privileges. )

- When the gamepad is turned off, press Triangle button and Home button, the three lights flash quickly.
- Open the bluetooth function of your phone and search the bluetooth device and click pairing to enter code "0000", then paired, the three lights still flash quickly.
- Install "Touch.apk" app, gain Root privileges, in the Application settings, click "Show popup window".
- Open Touch app, select device, select "bluetooth gamepad",click "virtual screen button" and "sliding mode", select Touch IME as input method. It will connect

- automatically.(Need to select the Touch IME in the Input setting.)
- e. Enter the game, press “select” button of the controller, the virtual buttons will come out, move the buttons onto the corresponding screen location.
  - f. Press “select” button of the controller to hide the virtual button, then press “Home” button to complete the setting. Now you can play games.
- **Icade mode:**(Note: This mode is only support IOS system.) Press Circle button and Home button to enter into Icade mode. Open the bluetooth function and search bluetooth device and click pairing to enter Icade mode. Now you can play the games.

**PS.** To shift Gamepad mode to Keyboard mode no need to turn off the gamepad, shift to APP mode need to turn off the gamepad and unpair the device. Android system is an open platform. Various game manufacturers design different standards. The gamepad can not support all the games. Please forgive this. Please try to use different modes to play the games when you not sure which mode works on the game.

### 3. Available games

- **Gamepad mode:**
- 1) Plasma sky
  - 2) Sine Mora
  - 3) Inertia: Escape Velocity HD
  - 4) Happy Vikings
  - 5) Dragon, Fly! Free
  - 6) Diversion
  - 7) Bike Mania Moto Free - Racing
  - 8) 9 Innings 2013
  - 9) Sonic
  - 10) Cordy
  - 11) Cordy2
  - 12) Shadowgun
  - 13) Sonic 4™ Episode I
  - 14) Sonic CD
  - 15) Sonic CD Lite
  - 16) Sonic The Hedgehog
  - 17) GTA 3
  - 18) GTA Vice City
  - 19) Speed racing
  - 20) Trial X,
  - 21) Virtua Tennis Challenge

- 22) Zen Pinball THD
- 23) Shine Runner THD
- 24) Gunslugs
- 25) Gunslugs Free
- 26) R-Type
- 27) TurboFly HD
- 28) Virtua Tennis Challenge
- 29) Virtua Tennis Challenge FREE
- 30) Wind Up Knight
- 31) Beach Buggy Blitz
- 32) Choplifter
- 33) Chuck's Challenge
- 34) Conduit HD
- 35) Razor: Salvation

.....(more games are being tested,welcome you to test the available games together)

➤ **Keyboard mode:**

95% of the Classical Emulator games are available.(Please download a emulator for your playing games.)

- 1)Metal Slug
- 2)Cadillacs and Dinosaurs
- 3)KOF
- 4)Street fighter
- 5)Teenage Mutant Ninja
- 6)Super Mario Bros.

.....

➤ **Key mode:**

- 1) Dungeon Hunter
- 2) Plasma sky
- 3) Riptide GP2
- 4) Sleepy Jack
- 5) Gunman Clive
- 6) Heliumboy

.....

➤ **Touch mode:**(Please get Root privileges of your device when you use this mode.)  
Support most games with virtual buttons.

- 1) Zenonia
- 2) Zenonia 2
- 3) Zenonia 2 Free

- 4) Zenonia 3
- 5) Zenonia LITE

... ..

➤ **Icade mode:**

- 1) Midway Arcade - Warner Bros.
- 2) PAC - MAN for iPad - Namco Networks America Inc.Games
- 3) Super Lemonade Factory - Shane Brouwer
- 4) Blast Ball - UNCADE
- 5) Gold Runner - YOMEN,Inc.
- 6) Kung Fu Rabbit - Bulkypix
- 7) Retro Racing - Mr Qwak Limited
- 8) Muffin Knight - Angry Mob Games
- 9) Minotron: 2112-Llamasoft
- 10) Velocispider - Retro Dreamer
- 11) No Gravity - Realtech VR
- 12) Super Mega Worm - Deceased Pixel LLC
- 13) Space Inversion - Silverline Arts
- 14) Sideways Racing - Bjango
- 15) Emerald Mine - Les Bird
- 16) Freesh - Realtech VR
- 17) Commodore 64 - Manomio LLC
- 18) The Exterminator - SUMO Productions
- 19) IronStar Arena - Appracatappa,LLC.
- 20) Compression HD - Little White Bear Studio, LLC
- 21) Mos Speedrun - Physmo
- 22) Warblade HD - Edgar Vigdal
- 23) Plum Crazy - Claymore Games
- 24) HungryMaster - xionchannel
- 25) Cyborg Livestock - PopArcade
- 26) Space Inversion 2. - Silverline Arts
- 27) Stardash - OrangePixel
- 28) Super Drill Panic - OrangePixel
- 29) GoatUp - Llamasoft
- 30) Minotaur Pescue - Llamasoft
- 31) Bob's Action Racing - VariaMedia GmbH
- 32) Silverfish MAX - Chaotic Box
- 33) Retroid - Flat Black Films
- 34) Box Cat - Rusty Moyher
- 35) Fruity The Snake HD - 22Moo
- 36) AirAttack HD - Art In Games
- 37) Temple Run - Imangi Studios, LLC
- 38) Haunted Hallway - UNCADE
- 39) HyperBowl - Technicat,LLC

40) Battlestation - CrushCrumble

41) Jungool - Headsoft

42) Influx - HalfFast Games

#### **4. Announce**

The games offered for different modes are just part of the games that the gamepad works on. Please download more games if needed. Please note again that the gamepad not support all the games.

#### **5. FCC STATEMENT**

1.This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

3. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help