

## **Thank you for choosing CARFONE CP200**

The CARFONE CP200 is the world's first car phone based on 3G technology.

The device supports a variety of applications and navigation services, has a large display of 3.5" and a large spaced buttons, especially designed to enable your safe and easy use while driving.

The device was developed with a thought to vehicle environment, the special requirements an automobile has for the operation of a cellular phone, prominently stressing audio quality, dialing ease, and quick response. During development the device underwent a series of exacting tests, meeting the standards concerning operation in vehicular environment.

Safe and correct installation by our installation instructions will provide you with a safe and pleasant driving experience.

This manual will assist you in discovering the VOYAGER's world of possibilities. It contains information on all its characteristics and innovations to assist you in operating the phone in the most easy and efficient manner.

\* Depending on your network operator.

## Table of Contents

|   |           |
|---|-----------|
| <b>1. Safety Directives .....</b>                   | <b>4</b>  |
| <b>2. Getting to Know the Phone .....</b>           | <b>6</b>  |
| 2.1 Kit Contents.....                               | 6         |
| 2.2 Device Structure.....                           | 7         |
| 2.3 Key Functions.....                              | 9         |
| 2.4 View Screen Symbols .....                       | 10        |
| 2.5 Basic Operations .....                          | 11        |
| 2.5.1 Switching the Device On.....                  | 11        |
| 2.5.2 Switching the Device Off.....                 | 11        |
| <b>3. Calls .....</b>                               | <b>11</b> |
| 3.1 Receiving a Call .....                          | 11        |
| 3.2 Making a Call.....                              | 12        |
| 3.2.1 Making a Call using the keyboard.....         | 12        |
| 3.2.2 Making a Call from the Call Log.....          | 12        |
| 3.2.3 Making a Call from the Contact list .....     | 13        |
| 3.2.4 Available Options During an Active Call ..... | 14        |
| <b>4. Contacts .....</b>                            | <b>15</b> |
| 4.1 Searching for a Contact.....                    | 15        |
| 4.2 Add a new Contact .....                         | 15        |
| 4.3 Edit a Contact .....                            | 15        |
| <b>5. Email .....</b>                               | <b>16</b> |
| 5.1 Setting an account.....                         | 16        |
| 5.2 View email message .....                        | 19        |

|           |                                 |           |
|-----------|---------------------------------|-----------|
| 5.3       | Sending email message .....     | 19        |
| <b>6.</b> | <b>Settings menu.....</b>       | <b>20</b> |
| 6.1       | Wireless & Networks .....       | 21        |
| 6.2       | Device.....                     | 22        |
| 6.3       | Personal .....                  | 23        |
| 6.4       | System.....                     | 24        |
|           | <b>Telephone Warrenty .....</b> | <b>20</b> |

## 1. Safety Directives

**Note:** It is recommended to read this chapter before using the device for the first time. The manufacturer will not be held responsible for any damage resulting from abnormal use or usage contrary to instructions appearing in this manual.

### Service!

Do not dismantle the device installed or its accessories. In case of failure, please contact your nearest service center.

### Vehicle!

The RF signals might affect electronic systems inappropriately installed in motorized vehicles or that are not properly protected. Consult your vehicle manufacture or his representative. Prior to installing any equipment in your vehicle, you must consult with the equipment manufacturer.

### Vehicles with installed airbags!

Airbags inflate with great power. When installing the device in the vehicle, the installing technician must verify that the device is installed in a safe distance from the airbag. Any installation that blocks the inflating airbag might cause very serious injuries.

### **Devices with warning signs!**

Make sure you turn off your phone whenever a warning sign asking so appears.

### **Turning off the device in risk of explosion!**

Places susceptible to explosion are fueling areas such as gas stations, areas with high content of chemicals, grains, dust or metal dust in the air and any other area where it is recommended to turn the motor off. In these places you need to turn off the device and follow instructions and signage.

### **Antenna**

When installing the device, a designated antenna fitted for use with this device will be installed in your vehicle. You must use only the original antenna supplied with the device or any other antenna approved for use by TCL. Any use of unauthorized antenna, or changes or additions made to the antenna might cause damage to the device and affect its quality of use.

## 2. Getting to Know the Phone


### 2.1 Kit Contents


The device unit that you purchased contains the following original items:

- TCL VOYAGER device
- Cables set
- Microphone
- Speaker
- Cellular antenna
- GPS antenna
- Swivel mount
- Screws set
- User Manual
- Pocket guide

**Notes:** We made the utmost effort to ensure that the product arrives to you complete and in order. In case some fault is discovered, please immediately contact the point of sale.










## 2.2 Device Structure




















## 2.3 Key Functions


|   |   |
|---|---|
|  | In Standby Mode – Shift to general call record (“All calls”)<br>When receiving a call – answer incoming call<br>After keying in numbers – call is dialed<br>During call – shift to call waiting |
|  | During call – call disconnected<br>Incoming call – reject incoming call<br>In Menu mode – Return to Standby Mode<br>Touch and hold – Switch phone On/Off  |
|  | Access available options  |
|  | Short press:<br>Outside Home page – Back to Home page<br>In Home page – Show all screens<br>Long press:<br>Show recent used applications  |
|  | Search Phone and Internet contents  |
|  | Back to previous screen   |
|  | In Text Edit Mode – Change writing mode   |
|  | In Text Edit mode – Add space   |
|  | In Standby Mode – Change income call ring volume<br>In Talk mode – Change talk volume   |
| Emergency call key  | Press 5 seconds to initiate a call  |

## 2.4 View Screen Symbols


|   |   |
|---|---|
|  | Received signal strength for the chosen network |
|  | No SIM card                                     |
|  | HSPA Connected                                  |
|  | UMTS Connected                                  |
|  | Transferring data                               |
|  | Bluetooth is on                                 |
|  | Flight mode                                     |
|  | Silent mode                                     |
|  | Wi-Fi is on                                     |
|  | Email message                                   |
|  | Call  |
|  | End call  |
|  | No sound  |
| HotSpot<br>Wi-Fi Icon   | Portable active HotSpot                         |

## 2.5 Basic Operations

### 2.5.1 Switching the Device On

In order to switch on the device, touch and hold the key . If the device is connected to the vehicle's ignition switch, the device can be switched on by starting the vehicle.



### 2.5.2 Switching the Device Off

In order to switch off the device, touch and hold the key  and touch **Power off**. If the device is connected to the vehicle's ignition switch, the device can be switched off by shutting the vehicle off (if the device is not in call mode).

## 3. Calls




### 3.1 Receiving a Call


When receiving a call, the device's view screen will change its display and show incoming call details.

- To accept the call, touch .
- To reject the call or disconnect at call's end, touch .

## 3.2 Making a Call

### 3.2.1 Making a Call using the keyboard


Key in the desired number. To correct the dialed number, touch the  key or  to delete the last digit. Touch  to make the call.






To disconnect at call's end, touch .


### 3.2.2 Making a Call from the Call log

The call log displays the last calls made.


In Phone mode touch  or  the Phone apps





Touch  to choose from the last calls: Missed calls ,  
outgoing , incoming , outgoing&incoming .

After locating the requested record, touch **Call to** or .


### 3.2.3 Making a Call from the Contact list

Touch  to enter the contacts list.



After locating the contact, touch .

### 3.2.4 Available Options During an Active Call



During an active call, the following additional actions are possible:

- **End** – end call
- **Call on hold** – hold the call
- **Mute** – silent the microphone
- **Dial pad** – screen dial pad
- **Changing volume**
- **Conference call**

## 4. Contacts


### 4.1 Searching for a Contact



Touch  to enter the contacts list.


Slide with your finger up/down to find a contact.




Or touch  to search by name.

### 4.2 Add a new Contact



Touch  to enter the contacts list.



Touch  to add a new contact.

Choose the desire saving place for the new contact.

### 4.3 Edit a Contact



Touch  to enter the contacts list.

Slide with your finger up/down to find a contact.


## 5. Email

### 5.1 Setting an account




Touch  to enter the email app.

If you have not set up an email account, the device will automatically start a process of adding email, and an email wizard will guide you through the steps to set-up an email account.




Type an email address and a password.






Touch **Next**.




Touch **Exchange**.




Now you now have to set the parameters for the account.

To create another account, touch **Settings/Accounts & Sync** and select **Add Account**.





Notice that you need Wi-Fi connection or active internet connection for sync the account.

## 5.2 View email message

Touch  to enter the email app.  
Scroll to the message and touch it.

## 5.3 Sending email message

Touch  to enter the email app.  
Touch  to create a new email message.


## 6. Settings menu

Settings menu includes all the settings of the applications and phone menus.

Touch **Menu** key.



Touch **Settings** to enter settings menu.



## 6.1 Wireless & Networks

|             |  |
|-------------|--|
| WLAN        | Select Wi-Fi on/off. After enabling Wi-Fi, touch WLAN. The device will search and display available networks. Select a network to connect to. If the network secure, you will be required to enter a password. |
| Bluetooth   | Select Bluetooth on/off. After enabling Bluetooth, you can access Bluetooth settings.  |
| Data usage  | Set mobile data limit  |
| Flight mode | Turn off all wireless connections and communications.  |
| VPN         | Setting and manage Virtual Private Networks.   |

|                              |  |
|------------------------------|--|
| Tethering & portable hotspot | You can make the device wireless router or router that can connect to it via USB cable and share your device's data connection with other devices. |
| WLAN Direct settings         | Connecting two devices via WLAN without requiring an access point.   |
| Mobile networks              |  |

## 6.2 Device

|                         |                       |
|-------------------------|-----------------------|
| Sound settings          | Volume                |
|                         | Silent mode           |
|                         | Headset media         |
|                         | Phone ringtone        |
|                         | Notification ringtone |
|                         | Dial pad touch tones  |
|                         | Touch sound           |
|                         | Screen lock sound     |
| Display                 | Brightness            |
|                         | Wallpaper             |
|                         | Sleep                 |
|                         | Font size             |
| SD card & phone storage | Internal storage      |
|                         | SD CARD               |

|              |                            |
|--------------|----------------------------|
|              | USB STORAGE                |
| Applications | Manage applications        |
|              | Preferred install location |

### 6.3 Personal

|                   |                           |
|-------------------|---------------------------|
| Accounts & sync   |                           |
| Location services | Google's location service |
|                   | GPS satellites            |
| Security          | Set up screen lock        |
|                   | Set up SIM card lock      |
|                   | Make passwords visible    |
|                   | Device administrators     |
|                   | Unknown sources           |
|                   | Trusted credentials       |
|                   | Install from SD card      |
| Language & input  | Language                  |
|                   | Spelling correction       |
|                   | Personal dictionary       |
|                   | Default                   |
|                   | Voice search              |
|                   | Text-to-speech settings   |

|                  |                    |
|------------------|--------------------|
|                  | Pointer speed      |
| Backup and reset | Factory data reset |

## 6.4 System

|               |                       |
|---------------|-----------------------|
| Date & time   | Automatic date & time |
|               | Automatic time zone   |
| Accessibility | Big text              |
|               | Speak passwords       |
|               | Touch and hold delay  |
|               | Install web scripts   |
| About phone   | System updates        |
|               | Status                |
|               | Model number          |
|               | Android version       |
|               | Baseband version      |
|               | Kernel version        |
|               | Version number        |



## Telephone Warranty

### Definitions

“**Huizhou TCL Mobile Communication Co., Ltd.**”: Device manufacturer.

Accel Telecom Ltd. . as the sole importer of cellular devices to Israel. Accel Telecom Ltd. will provide the warranty services for cellular phones imported.

“**The Product**”: Cellular phone manufactured by Huizhou TCL Mobile Communication Co., Ltd..

“**Customer**”: Whomsoever legally holds the product and the warranty document.

“**Authorized dealer**”: An entity authorized by Huizhou TCL Mobile Communication Co., Ltd. or by the cellular communications network operator to market “the product”.

“**Mobile radio telephone system**”: Cellular mobile radio telephone systems.

“**Authorized service point**”: A service point/laboratory providing technical services for Huizhou TCL Mobile Communication Co., Ltd. cellular phones and other authorized accessories, authorized by Huizhou TCL Mobile Communication Co., Ltd. or by the cellular communications network operator. A list of authorized service points operated

by Huizhou TCL Mobile Communication Co., Ltd. is attached to this warranty.

**“Point of Sale”:** A point of sale offering the product for sale.

**Accel Telecom Ltd. is liable towards the customer only for any defects in workmanship and/or materials, providing that the product has been used in a proper and reasonable way, subject to the following.**

The service hereunder will be provided by Accel Telecom Ltd. subject to the following terms:

- 1 The warranty for this product will be provided for a period of one year (12 months) (the “Warranty Period”).  
Notwithstanding the above, when a customer is not defined as a “consumer” by the 1981 Consumer Protection Law, the warranty for the battery will only be valid for 6 months. The Warranty Period begins when the product is delivered to the customer. The Warranty Period for product accessories is specifically defined in the packaging of each item.
- 2 The warranty is only valid for products imported into Israel by Accel Telecom Ltd.
- 3 A “product” found to be defective during the Warranty Period as a result of defective materials and/or normal use, will be repaired by Accel Telecom Ltd. or the defective parts or those that did not function according to the technical specifications will be replaced with new and original parts, at the sole discretion

of Huizhou TCL Mobile Communication Co., Ltd. and at its expense, and Huizhou TCL Mobile Communication Co., Ltd. will provide the customer with a confirmation that the repair has been carried out, which will include the details about the nature of the repair and the parts replaced.

In the event that a product will not be repaired – Huizhou TCL Mobile Communication Co., Ltd. will supply the customer with a new and identical product, or a product of similar and equivalent type and quality, or will reimburse the customer for the price of the device, all at Huizhou TCL Mobile Communication Co., Ltd.'s discretion. The obligation to make such repairs as described in this section is subject to the instructions and limitations included in this warranty.

- 4 Customer acceptance of the product constitutes the customer's confirmation that the external packaging of the product and its external parts: including screen, keyboard, etc., are brand new and are free of defects at the time of purchase by the customer.
- 5 In the event that the product was repaired or replaced by Huizhou TCL Mobile Communication Co., Ltd. – the repaired or replaced product will be covered by this warranty for the remaining Warranty Period. The Warranty Period will not be extended beyond the original Warranty Period due to repairs and/or replacements. In the event

that the defective product or its parts were replaced, such product or parts will become the property of Huizhou TCL Mobile Communication Co., Ltd. after their replacement.

- 6 Whenever the customer wants to activate the warranty, the customer must present this warranty, and at Huizhou TCL Mobile Communication Co., Ltd.'s discretion, also provide a written proof of the product's purchase date.
- 7 The customer will cover any expenses incurred in shipping/delivering the product to or from the service point.
- 8 The product will be repaired within ten working days from the date it was delivered to an authorized service point, or alternatively, within 14 days from the date it was delivered to a point of sale. Saturdays and holidays will not be included in the above periods.
- 9 This warranty does not cover any installations and/or repairs to any systems that are not "the Product".
- 10 In case that the product defect appeared during the warranty period was resulted in by any of the events listed below, Huizhou TCL Mobile Communication Co., Ltd. and/or the service point, will notify the customer before carrying out the repair, and in such cases, the customer will be obliged to pay Huizhou TCL Mobile Communication Co., Ltd. and/or the service point authorized on its behalf, for the transportation, shipping, work, materials, components, accessories, and the like, which were

required for carrying out the work, based on an Accel Telecom pricelist valid at such time.

In events where product defects were caused by improper and/or unreasonable use and/or handling which does not conform to Huizhou TCL Mobile Communication Co., Ltd.'s instructions and/or negligence, neglect, defective maintenance, breakage, penetration of liquids, excessive humidity, improper storage, repairs and/or installations and/or additions and/or changes and/or any kind of technical handling by any entity and/or person and/or service point, which have not been authorized to do so by Huizhou TCL Mobile Communication Co., Ltd., accidents (including, but not limited to: fall, breakage, lightning strike, liquids, fire), burnt fuses and/or use of accessories (such as charger and/or battery) not approved by Huizhou TCL Mobile Communication Co., Ltd. and/or Huizhou TCL Mobile Communication Co., Ltd., and/or any other reason not related to Huizhou TCL Mobile Communication Co., Ltd. and/or Huizhou TCL Mobile Communication Co., Ltd..

- 11 This warranty will not apply to the product, and the customer will not be compensated by this Warranty in the following events:
- The customer did not submit the product for repair in the course of the Warranty Period.
  - Defects which were caused by intentional vandalism.

- The identifying serial number on the product's identification label or the date code on the accessory – have become unreadable and/or were removed and/or were erased and/or were changed.
  - Where lack of availability and/or operational range and/or coverage by the cellular service and/or malfunctions in the "mobile radio telephone" system operated by and on behalf whosoever was authorized to do so by the Minister of Communications and/or because of excessive loads on their wireless system and/or because of any wireless disruption which are not caused by any product defects.
- 12 Huizhou TCL Mobile Communication Co., Ltd.'s and Huizhou TCL Mobile Communication Co., Ltd.'s overall liability in case of claims for any damages caused as a result of using the product, regardless of the circumstances in which the damage was caused, will in no case exceed the original purchase price of the product. In no case will Huizhou TCL Mobile Communication Co., Ltd. and Huizhou TCL Mobile Communication Co., Ltd. have any liability for indirect and/or special and/or consequential and/or accompanying damage, neither directly nor indirectly, neither by accident nor as a result of using the product, including, but not limited to, any losses in income and/or profit that may occur to the customer and/or a third party, as a consequence of non-use of the

product or accompanying equipment, and any claims by a third party following the use of the product.

- 13 Except for the explicit liability undertaken by Huizhou TCL Mobile Communication Co., Ltd. and Huizhou TCL Mobile Communication Co., Ltd. under this warranty, Huizhou TCL Mobile Communication Co., Ltd. and Huizhou TCL Mobile Communication Co., Ltd. have issued no other warranty or obligation, neither in writing nor orally. The entire liability for the products or their usage, including, but not limited to, their conformity for use, will be subject to the provisions of this warranty alone.
- 14 Until the end of the Warranty Period (or in the event that the product price at the time of purchase exceeds NIS 300 – over the course of an additional year following the end of the Warranty Period), the customer is entitled to purchase spare parts from Huizhou TCL Mobile Communication Co., Ltd. at Accel Telecom's list price, in order to repair the product.
- 15 An authorized dealer and/or an authorized service point and/or an entity or/person of any kind that have not been authorized by Huizhou TCL Mobile Communication Co., Ltd. and/or Huizhou TCL Mobile Communication Co., Ltd. to issue a Warranty and/or obligation of any kind that exceed the limits of this warranty.

- 16 The warranty provided herein is only valid within the borders of the State of Israel. The only laws that will apply to the provisions of this warranty are the laws of the State of Israel. The sole jurisdiction applicable to all matters pertaining or relating to this warranty is that of the competent courts in one of the following four cities: Beer Sheba, Tel Aviv, Jerusalem, Haifa.



Accel Telecom Ltd. reserves the right to alter material or technical specification without prior notice.

**FCC Statement:**

This Carfone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

**RF exposure statement:**

The transmitter must not be co-located or operated in conjunction with any other antenna or transmitter. This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

**IC Statement:**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.