






<p>All the users,thank you for purchasing our product. Please read this user manual carefully before use it. To know better of the operation method and instruction,make sure that use the product properly,bring the best performance into full play.</p> <p><b>1.Product Overview</b></p> <p>This is a portable multimedia speaker which is designed with unique and exquisite appearance, use for outdoor, indoor activities,office,meeting etc. Enjoy the comfortable and relaxing music conveniently,bring the best ever timbre from your audio productst(PC,digital musicplayer, Mobile phone)</p>	<p><b>2.Functions instruction</b></p>  <p><b>1) LED indicator screen</b></p> <p>Blue light flashing when serching for Bluetooth. Blue light constant illuminate when connect to bluetooth device successfully.</p> <p><b>2) Power/Play/Pause</b></p> <p>Press and hold to turn on or turn off,press once for play or pause. Press and hold for 5 seconds till the LED indicator screen flash fleetly to search</p>	<p>for Bluetooth.</p> <p><b>3) Volume control</b></p> <p>Press for volume up and down. There is a beep when adjust to max volume.</p> <p><b>4) Track control</b></p> <p>Press to skip previous and next song</p> <p><b>5) USB port</b></p> <p>Connect the included 5 Pin USB cable to PC USB interface or the DC 5V 500mAh adapter,and to the speaker DC input.</p> <p><b>6) Mic</b></p> <p>For the use of hands-free mobile phone calls</p> <p><b>7) LED indicator</b></p> <p>DC 5V charging indication. When</p>	<p>charging,the LED in red. When fully charged, the red LED indicator will turn off.</p> <p><b>8) Line-in/AUX/Reset</b></p> <p>Audio input,connect to PC,mobile phone,MP3/4/5 player,iPod. The Reset button is inside the line-in jack,when the speaker is out of order,please use the thin stick to plug into the line-in jack and press lightly,the speaker will restart, restore regular palying mode.</p> <p><b>3.Bluetooth set-up</b></p> <p>Turn on the speaker,blue LED indicator screen illuminate,choose bluetooth mode in your device,connect your device with speaker. When your device shows connected,the blue LED</p>	<p>indicator screen illuminate constant, you can play music under wireless mode.</p> <p><b>Notes:Connect Bluetooth to PC</b></p> <p>On a Windows operating system you need to open the control panel,then select “Sound” and then the “Playback” tab and then you can see the various audio devices available. Select the sound output as the default.</p> <p>On a Mac operating system select the main menu. “System Preferences” , “Sound” and “Output” . You should then see the Bluetooth speaker under the list of device. Select the “speaker stereo” as the default.</p>	<p><b>4.Product features</b></p> <ul style="list-style-type: none"><li>•Product dimension: L(197MM)*W(48MM)*H(40MM)</li><li>•Speaker ouput: 2*2.2 watt</li><li>•Speaker driver: 2*33mm</li><li>•Frequency: 20-20K Hz</li><li>•SNR: ≧80dBA</li><li>•AUV input sensitivity: 0.5V</li><li>•Distortion: ≦5%</li><li>•Battery: rechargable Lithium ion, 1000mAh. Ensure safety. For long time playing,environmentprotection,economy,practicality.</li><li>•Battery charge time: First charge 4 hours,2 hours thereafter</li><li>•Blackout memory system: momorize the song that quite last time and play it automatically.</li><li>•File format (for music file): MP3,WAV</li><li>•Bluetooth: support A2DP,AVRCP,</li></ul>
--	--	--	---	---	--

<p>range over 15 meters,compatible with V3.0,V2.1,V2.0 and V1.2 standard.</p> <ul style="list-style-type: none"><li>•Support audio input,connect PC, mobile phone and MP3 player easily.</li><li>•Easy link cable: with USB cable for charging,line-in cable and USB audio cable for music output.</li></ul> <p><b>5.What's in the box</b> Bluetooth speaker Micro USB cable Line-in cable User manal</p> <div></div>	<p><b>6.Additional information</b></p> <ul style="list-style-type: none"><li>•In order to prolong the speaker life and for your safety,listening to music in high volume for a long time is not recommended.</li><li>•Keep the speaker away from wet,high temperature and greasy environments, protect the speaker from direct sunlight and rain.</li><li>•If the speaker is out of order,please turn off the power source as soon as possible to prevent damage to the device.</li><li>•When the power is low,the speaker will turn off automatically,please charging promptly. If you don't use the speaker in a long time,please at least charge the speaker once a</li></ul>	<p>month,to protect the battery and prolong the battery life.</p> <ul style="list-style-type: none"><li>•If there is no beep sound when connecting,please make sure connect to the audio output interface properly.</li><li>•If the speaker can't play music,it maybe because the program can't recognize the MP3 music file,please be sure storage the file to the root in removable device.</li></ul> <p>FCC STATEMENT : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference,and</p> <p>(2) This device must accept any interference received, including interference that maycause</p>	<p>undesired operation. Warning:Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guaaantee that interference will not occur in a particular installation. If this</p>	<p>equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <p>Reorient or relocate the receiving antenna.</p> <p>Increase the separation between the equipment and receiver.</p> <p>Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</p> <p>Consult the dealer or an experienced radio/TV technician for help.</p> <p>RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>	<div><h1>Bluetooth Speaker</h1><h2>User Manual</h2></div>
---	--	---	---	---	---