



Bluetooth Speaker

User Manual

Thank you for choosing this Bluetooth Speaker , in order to you easily experience the product, we are equipped with detailed instructions for user , which you can get information about the product introduction , usage and other aspects of knowledge , when you use the speaker before first read the instructions carefully.

The Bluetooth speaker, Bluetooth software recognizes named : SY1001BC, when the code after connection can be achieved Bluetooth related features:



1. Notice

In order to properly use the speaker for user to ensure that speaker with good performance , please carefully read and follow :

- Do not severely impact the speaker.
- Do not touch benzene, thinner or other chemicals .
- Do not go near a strong magnetic field , electric field .
- Please avoid direct sunlight or heating appliances .
- Do not disassemble, repair , transformation.
- Cycling, driving and motorcycle , do not use the player and headphones, to avoid danger .
- Do not listen to a larger volume , so as to avoid adverse effects on hearing .
- Packaging waste , batteries, used electronic products, please classification properly handled.

2. Features

[**Bluetooth audio**] Bluetooth , Maximum receiving distance of 10m

[**Bluetooth phone**] voice clarity, no echo.

[**Mp3 Player**] IT card memory directly play MP3 files .

[Audio Input] stereo audio input interface, easy to connect computers, digital music players , cell phones and other audio devices.

[**USB card reader**] connected to a computer , you can copy or delete a song in TF card .

[**USB sound card**] connected to the computer , can play computer audio files .

[Internal battery] Internal rechargeable lithium battery, environmental protection , energy saving, practical.

[Decorative lamp control] Internal bright LED lights , to a decorative role (optional).

3. Play music operation

Boot automatically detect and identify the external device ,after boot into Bluetooth mode , insert the TF card automatically recognize the player , the latter priority principle Can also automatically switch the playback mode;audio signal line does automatically switch .

4. Product key and jacks feature definition (Please refer to our actual products)



A. Power Switching ; ON is Open , OFF is off ,LED is open or led light open



B. MUME/Play / Pause / Answer / Hang up the phone / mode switch
Short press : TF, AUX and Bluetooth mode to play / pause , press to answer the phone when a call ,short press to hang up.
Long press: press 3 seconds release the mode conversion, the conversion order TF -> Bluetooth -> AUX ->;When the Bluetooth state, to switch to another Bluetooth device , press [MUME / TEL / PLAY], enter another Bluetooth of code states.



C. Adjust the volume of small / previous one .

Short press : Bluetooth and TF mode is previous one ,; Long press: to adjust the volume decreases.



D. Adjust the volume of bigger / next one .

Short press : Bluetooth and TF mode for the next one ,
Long press: to adjust the volume increases.



E. Power charging , you can use this dedicated USB power cable connected to the computer 's USB port for charging.

F. Insert IT card to play MP3 music.



G. Call Microphones: Facing the microphone can enhances call quality.



H. stereo signal input interface

5. LED description

Red LED: charge indicator
Blue LED : TF, AUX, Bluetooth playback mode indicator .

6. Bluetooth connection method (Optional models , refer to our actual products)

A. Press the Mode button or switch power on to enter the Bluetooth mode , it will be have voice prompt sound , LED light flash .

B. Open mobile devices (cell phones, computers , etc.) of the Bluetooth function, search for Bluetooth devices "SY1001BC".

C. Manual clicks , the device automatically paired , connection, the connection is successful will be have voice prompt sound . (Under normal circumstances do not enter a password, special models prompted to enter a password , enter "0000 " can be) Different types of mobile phone,bluetooth pairing time will be different.

D. have been successfully paired devices ,it will automatically connect for next time.

E. Note : Enter Bluetooth mode within 10 seconds , the Bluetooth device will automatically find pair and connection ,after10 seconds going through the manual connection.

7. Charge Method

Plug the power cables into the [USB] connector and the other put into the computer's USB port, or DC5V output power adapter charging interface , Charging "Red Light" bright , full of " red light" off.

The machine built overcharge protection circuit can be connected to a computer or charger use prolonged , approximately three hours can be filled with battery ; battery life will vary depending on the volume and different time .

8. USB card reader and sound card usage.

Plug the USB cable into the [USB] jacks , and the other end of the USB into the computer's USB port.

1. TF card is not inserted , open the [LIGHT/ON / OFF] switch , issued a " boom " sound , the machine enters USB sound card mode.

2. Insert TF card, open the [LIGHT/ON / OFF] switch , the computer will pop up a "Removable Disk" drive , will be entered USB card reader mode.

9. low battery

When the battery lower ,Speaker will be emits three"dididi" short sound and warning ,the system will automatically shut down , then please charge ; if the machine is not used for a long time , at least charging every months , can protect the battery to extend battery life.

10. Troubleshooter

A. Q : A boot on automatically shut down ?
A : Battery not enough , please charge , recommended charging two hours before use

B. Q : Play blue LED have been shut down or reboot automatically ?
A : Battery not enough , please charge , recommended charging two hours before use

C. Q : Not charging
A : Please use this charging cable and make sure the USB port is connected voltage is normal

D. Q : Charging red LED does not light or red LED very dark ?
A : Normal . If the battery is fully charged or voltage is full , the charging red led will not light or very dark , in short, the battery power is lower, the red LED will be brighter when charging.

E. Q : Speakers without sound.

A : Determine the TF / Bluetooth / AUX mode, the playback status , and adjusted to the appropriate volume .

F. Q: AUX without sound?

- A : 1、 Please use the this of audio cable, and select the correct audio output interface.
2. Insert the USB cable into the AUX mode is not automatically , according to [M /TEL/ PLAY] key to switch to the AUX mode.
3. the external audio device volume is turned on or not .

G. Q: Bluetooth can not automatically connect ?

- A : 1、 Only paired just will connect automatically.
2. If the speaker after 10 seconds just open Bluetooth device ,speakers does not automatically connect .
3. Bluetooth detailed usage instructions , please refer to " Article "

H. Q: Bluetooth without sound?

- A : 1、 Make sure the Bluetooth is connected successfully .
- 2、 Bluetooth device's volume is turned on ?

I. Q: No function or function keys wrong ?

A : Powercycle !

J. Q: Card Reader / Audio function does not work ?

A : 1、 Be sure to use the standard data cable .

2. Must first plugged the cable to connect the computer to boot into the card reader / sound mode.
3. Please refer to detailed usage instructions " Article IX . "

11. Technical specifications

Output power(audio):	3W
Operating Voltage:	3. 7V
Frequency Response(audio):	80Hz-18KHz
Distortion:	≤1%
Audio input:	bluetooth, IF , AUX,USB
Support Mp3:	Bit Rate 32Kbps-320Kbps
Speaker unit :	4 Ω /3W
Power:	Built- in lithium battery 500mAh
	3. 7V or external DC5V
Adjusting:	buttons adjust
Input sensitivity :	450±50mV
Weight:	about 350g

12. Packing Accessories

Bluetooth speaker:	1 set
USB recharge cables:	1pcs
Audio cables:	1pcs
1 pcs manual(including the warranty card and certificate)	

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **Francase Limited** may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.