

FCC ID: 2AJN299169



MANUL OF 2.4G REMOTE CONTROL

(1) install the 2 AAA batteries in remote control

(2) Press any button on remote control, the light on remote control will start flashing. turn on the car, the mach light on the remote control will flashing- turn off-turn on, then match success, if unsuccessful, please try it again. (The first time match and change batteries, it needs to match again).

(3) After mach the remote control with car, the remote control has 3 levels speeds to change, the mach light on remote control has 3 kinds flash frequency, representative 3 different speeds.

Illustration of buttons : forward Δ backward ∇
turn left \curvearrowright turn right \curvearrowleft
pause P speed S





