



User Manual

Bluetooth Cassette



Specification

Frequency Response Range: 30HZ -- 15KHZ

Bluetooth Version: V4.0

Transmission distance: 10M

Playtime: 6 hours

Charging Voltage: 5V/1A

Charging Time: 2 hours

How to operate:

1. Press and hold the button to power on/off.
2. The blue/red indicator flashes quickly while the product searching for Bluetooth that could be paired.
3. Turn on the Bluetooth in your device settings and select "BW Cassette" to pair.
4. Insert the product into the cassette player and press PLAY
5. Select music on your device and enjoy the music.

Bluetooth Mode Operation:

Blue and red light flashing means it's in pairing mode.

Blue light is constantly on when there is a call coming.

Blue light flashes slowly when it playing music.

How to accept / reject / end a call

Accepting a call – Press the "on/off" button.

Rejecting a call – Press and hold the "on/off" button.

Ending a call - Press the "on/off" button.

If there is enclosed cassette slot in your car, please don't use this cassette to operate the phone calls.

Charging Mode:

Red light is constantly on when product is charging.

Product is fully charged, then the red light automatically switches off.

When the power is low, red / blue light flashes quickly.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.