

gooseberryTM

a little more for those who need to know :)



our philosophy

Our planet is our home. Humanity has advanced technologically and created a system where new material desires constantly emerge around and within each of us. While we value our possessions, we continue to acquire new products and gadgets for our daily life at an astronomical rate.

We must stop for a moment and rethink our methods. Can we live with a middle way approach, where we adopt new technologies without obsoleting old ones?



At gooseberry, we believe that as a society, we can choose to rejuvenate our possessions by “smartening” them. This allows each of us to conserve more and to re-use more without compromising our lifestyles, whether keeping fit, hanging out with friends, at work or at play.

Our offerings are targeted to extend the life of your products and gadgets and in the process rejuvenate your experience technologically.

We choose to pursue a mindful trade with a meaningful purpose.

Know your gooseberry, its simple.

- 1** Ssh Please | Encore!
- 2** Turn me On | Connect | Pick Up
- 3** Turn it Up | What's Next?
- 4** LoveClip
- 5** HeartGlow - Red and Blue LED
- 6** Connect your Headphone
- 7** Juice me up!



Bring me to life


If you are lucky I may still have some juice (charge) in me when I arrive. But to be honest if you juice me for up to 30 minutes, I will be ready to go for up to 6 hours.

So, connect the small cable to my energy point {7} and let me be for a while. You will see my HeartGlow {5} come alive. When I am fully juiced (charged), the RED light will disappear.


Turn me "On" {2} and my HeartGlow will start blinking.

There is one more step left, that is, of "pairing" me with your device (a Bluetooth connection to your phone, tablet, computer) to experience wireless gooseberry freedom.


Style



On your Belt,



or your Tee,



even on your Sleeve.


Show me off in style

Your style, your imagination.
You choose how you want to wear me,
I am super simple to adopt.

Simply remove my LoveClip {4} and stick your
sleeve or t-shirt between me and the clip.
I will be hanging in there with you no matter
what - whether you are dancing, running or
just chilling at home.

Pairing Me

“Pairing Me”, with your phone, music player, tablet or computer




Before your start, turn me “ON” {2}. Bring me close to your device and then follow the steps below, it is quick and simple.

For Your iOS / Mac OS and Android

Turn Bluetooth ‘ON’ on the device you are pairing with.

Next, turn ‘ON’ your gooseberry.
The Blue LED {5} will start blinking.
(It’s searching for a device to pair with)
Now you will be able to pair me with your device successfully. Once connected, my Blue LED will stop blinking.

Using Me



While listening to Music / Video

Press {−} or {+} once to shuffle between songs

Press {⏸} once to play/pause your movie or song

Press and hold {−} or {+} to increase/decrease the volume

While accepting a Call

Press {⏸} once to accept/put a call on hold

Press and hold {−} or {+} to increase/decrease the volume

While Pairing your gooseberry

Press and hold {⏸} to turn on/turn off your gooseberry

Press twice {⏸} to begin pairing in 'social mode'



Social Mode
Two friends, One track, two gooseberrys
in harmony together :)

Social Mode - I love socialising!

This is my favourite mode. You and your friend can both FEEL the social experience - wirelessly. Both of you just needs one gooseberry each.

When two "gooseberrys" are connected and then paired with your device of choice... Voila! - both of you can hear the same tracks at same time.

Bonding with your friend's gooseberry

We suggest you to connect your earphones to the gooseberry and wear them while 'bonding' so you can hear when they have successfully 'bonded'.

If your gooseberry is already paired with a device (phone or computer, tablet or car) then disconnect or unpair it...

Social mode in 60 seconds

Turn off both gooseberrys. Long press the power button on both and turn them on, upon which the Blue LEDs will start blinking.

page 13

Double click the power button on any one of the gooseberrys, which will then automatically pair it with the other gooseberry within 60 seconds or so.

(You don't need to double click on both the gooseberrys to pair)

Once both the gooseberrys are paired you will hear "second device connected successfully" in your earphones, please allow a few seconds for the Blue LED to stop blinking.

Once both the Blue LEDs have stopped blinking go to your device's (phone or computer, tablet) Bluetooth Settings and turn on Bluetooth (if not 'ON' already).

Simply select "gooseberry" to connect/pair with your phone or computer. You will hear 'device connected' in your earphones once it's successfully connected.

You and your friend are now free to enjoy listening to the same music, watching the same movies and dancing to the same beat.

Share the love and feel wireless freedom together :)

Some of the Apps that love gooseberry :)

**Phone, Skype, Facetime, Viber,
WhatsApp and WeChat**

You can receive Voice/Video/VOIP on your gooseberry by pressing the power button to accept the call. If you wish to switch to speaker mode, simply click the 'speaker icon' on your phone or computer. You should be able to continue your conversation loud and clear.

Netflix, Youtube, iTunes

In the same way that you use gooseberry to listen to music you can also watch your favourite movies. Simply play/pause, adjust your volume, sit back and enjoy :)

A few words we have to print...

Returns and Warranty

We believe in taking responsibility to make sure your experience using gooseberry does not diminish due to technical reasons. so our warranty policy is designed to offer you a genuine protection against the product. For more information regarding returns and warranty please visit www.gooseberry.store

Trademarks

gooseberry is a trademark of CU Wellness, Inc. and all other marks are trademarks or registered trademarks of other third parties, including without limitation: iOS is a trademark or registered trademark of Cisco in the US and other countries and is used under the license to Apple Inc. Mac OS X is a trademark of Apple Inc. Android is a trademark or registered trademark of Google.

Battery Precautions

We advise you read, follow and keep these safety instructions to prevent any health, environment - related accident. gooseberry comes with a built in non-changeable battery. Do not attempt to remove/replace it. Charge the battery with the provided micro USB cable. We recommend you use a certified laptop or USB power supply to charge.

Safety Instructions

We advise you read, follow and keep these safety instructions to prevent any health, environment related accident. gooseberry is not a toy. It contains small parts, which can be a choking hazard. Please keep away from children. Do not tamper, modify, disassemble gooseberry. Your warranty and returns may be annulled accordingly. Please check our warranty and returns terms at www.gooseberry.store Handle with care and keep gooseberry away from sources of heat, especially open flames. Use clean, soft and dry cloth to clean your gooseberry. Do not use abrasive agents. Do not place gooseberry in a dishwasher, washing machine or dryer. This may damage the internal/external parts.

Product Disposal

Please take a moment and consider the environment. Please do not dispose gooseberry with common household waste as it is considered electronic waste and should be disposed of at your local electronic equipment collection facility. For more information, we recommend you contact your local electronic waste management authority.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



www.gooseberry.store

Send us some love @gooseberryworld

