

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:



CYCLONE mode = maximum CHAOS

360° SPINS



DUAL ACTION

WARNING:
CHOKING HAZARD - small parts.
Not for children under 3 years.

FORCE1 CYCLONE
FAST ACTION STUNT CAR

Built for superior shock absorption, delivering incredible off-road torque

**INCREDIBLE PERFORMANCE
FREESTYLE STUNT ACTION
SUPER FAST**

BATTERY SAFETY INFORMATION

- Do not expose product to fire, otherwise the batteries may explode or leak.
- Dispose of the batteries safely.
- Ensure the batteries are not short-circuited.
- Exhausted batteries are to be removed from the product.
- Batteries are to be inserted with the correct polarity.
- Only batteries of the same or equivalent type should be used.
- Don't mix alkaline batteries with rechargeable batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Non-rechargeable batteries are not to be recharged.
- To avoid battery leakage!
- In exceptional circumstances, the batteries may leak fluids that can cause a chemical burn injury or ruin your product.

CAUTION:

- Keep fingers, hair and loose clothing away from the Cyclone while it is on.
- Adult supervision is recommended when the Cyclone is in use.
- To avoid accidental or unwanted operation, remove all the batteries when not in use.
- Always turn the Cyclone off before removing the batteries.



FORCE1

CYCLONE
FAST ACTION STUNT CAR



**DOUBLE SIDED
FREESTYLE STUNTS**

CYCLONE
FAST ACTION STUNT CAR

AGES 6+



360° SPINS


**DOUBLE SIDED STUNTS
DOUBLE THE ACTION**

FORCE1

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

VEHICLE



Battery Installation:

1. Unscrew the battery compartment cover on the black and red side of the Cyclone (screwdriver not included).
2. Insert 3.7v rechargeable battery pack. Carefully attach the connector of the battery to the connector of the car. Make

TRANSMITTER



Battery Installation:

1. Open the battery compartment cover.
2. Insert 4 AA batteries with polarity (+/-).