

ENGLISH

INSTRUCTIONS

For detailed instructions on how to use your product, please visit <http://grainaudio.com/pages/user-guides>

REGISTRATION

Thanks for purchasing this Grain Audio product — you're going to love it. Please take a few minutes to go to [www.GrainAudio.com](http://www.GrainAudio.com) and register.

Why register?

- **Warranty** – registering your product with us will extend your warranty from one year to two
- **Product Updates** – allows us to contact you with important product notifications
- **Confirmation of Ownership** – provides a record in case of product loss or theft
- **Improved Product Development** – helps us continue to design products that make you happy

BATTERY

This Grain Audio product contains a rechargeable lithium-ion battery. It should only be charged with the charger provided with this product. Should your battery need replacement within the warranty period, we've got you covered. Grain Audio provides a battery replacement and recycling service that you can access through our website. Please DO NOT attempt to open this product or replace the battery yourself; really, it's a bad idea. In fact, opening the product voids the limited warranty.

CARE AND FEEDING

This is a real, solid wood product. Wood is a great material for making audio products, its resonant qualities cannot be matched by man-made plastics or composites. Wood is also a beautiful material, and the natural color and grain variations inherent to the wood are part of this beauty.

Being made from a natural material there are a few precautions to take when using your Grain Audio product.

1. **Keep things dry.** Wood (and electronics by the way) don't like being wet or submerged in liquid... steam saunas aren't great places for them either. Please keep this in mind.
2. **Take care.** The wood housing of your Grain Audio product will take some bumps and bruises. Unlike harder plastics these scrapes may show but that's okay; these will not affect the sound quality of your product. Plus, it'll make you look cool.
3. **Shade.** Wood will change color over time. This is a result of the natural interaction between the wood, oxygen and sunlight. We're pretty sure you can't control the aging content in the air around your Grain Audio product but you can keep it out of prolonged exposure to direct sunlight. No sunscreen though, that would be bad.
4. **Finish.** The wood in your Grain Audio product is protected by a durable water resistant finish. It is designed to last the life of the product and should not need refinishing. However, an occasional cleaning with a soft cloth will help keep things pretty.

LIMITED WARRANTY

**What Does The Warranty Cover?:** Grain Audio warrants that its products shall be free from defects in materials or workmanship, with the exceptions stated below.

**What Is The Period Of Coverage?:** This warranty runs for one year from the date of purchase, two if you register your product on [www.GrainAudio.com](http://www.GrainAudio.com). The term of any warranties implied by law shall expire when your limited warranty expires. Some states and/or Member States in the European Union do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

1. **Keep things dry.** Wood (and electronics by the way) don't like being wet or submerged in liquid... steam saunas aren't great places for them either. Please keep this in mind.
2. **Take care.** The wood housing of your Grain Audio product will take some bumps and bruises. Unlike harder plastics these scrapes may show but that's okay; these will not affect the sound quality of your product. Plus, it'll make you look cool.
3. **Shade.** Wood will change color over time. This is a result of the natural interaction between the wood, oxygen and sunlight. We're pretty sure you can't control the aging content in the air around your Grain Audio product but you can keep it out of prolonged exposure to direct sunlight. No sunscreen though, that would be bad.
4. **Finish.** The wood in your Grain Audio product is protected by a durable water resistant finish. It is designed to last the life of the product and should not need refinishing. However, an occasional cleaning with a soft cloth will help keep things pretty.

is no longer being manufactured, or is out of stock, at its option, Grain Audio may replace your product with a similar or better Grain Audio product.

**How To Get Warranty Service:** To get a covered product repaired or replaced, you must contact Grain Audio during the warranty period by email ([support@grainaudio.com](mailto:support@grainaudio.com)) or via the Contact Us form on [www.GrainAudio.com](http://www.GrainAudio.com). You must include in your email, your name, address, email address, telephone number, date of purchase and a complete description of the problem you are experiencing. If the problem appears to be related to a defect in material or

CUSTOMER SERVICE

The answers to most setup and performance questions can be found in the Troubleshooting guide. You can also consult the FAQs in the customer support section of our Web site at [www.GrainAudio.com](http://www.GrainAudio.com).

If you live in North America and still can't find the information you need, please contact our customer service team via email below or the Contact Us form on [www.GrainAudio.com](http://www.GrainAudio.com) for assistance before returning the products to your retailer under their return policy. Email: [support@grainaudio.com](mailto:support@grainaudio.com)

If you live outside of North America, please visit our website at [www.GrainAudio.com](http://www.GrainAudio.com) and select your region to locate your country's distributor.

International customers: For information regarding the distribution of Grain Audio products in your country, please visit [www.GrainAudio.com](http://www.GrainAudio.com) and click on your region.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

CUSTOMER SERVICE

The answers to most setup and performance questions can be found in the Troubleshooting guide. You can also consult the FAQs in the customer support section of our Web site at [www.GrainAudio.com](http://www.GrainAudio.com).

If you live in North America and still can't find the information you need, please contact our customer service team via email below or the Contact Us form on [www.GrainAudio.com](http://www.GrainAudio.com) for assistance before returning the products to your retailer under their return policy. Email: [support@grainaudio.com](mailto:support@grainaudio.com)

If you live outside of North America, please visit our website at [www.GrainAudio.com](http://www.GrainAudio.com) and select your region to locate your country's distributor.

International customers: For information regarding the distribution of Grain Audio products in your country, please visit [www.GrainAudio.com](http://www.GrainAudio.com) and click on your region.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

IC Radiation Exposure Statement

This EUT is compliance with SAR for general population/uncontrolled exposure limits in IC RSS-102 and had been tested in accordance with the measurement methods and procedures specified in IEEE 1528.

**European Union notice**  
Products with CE marking comply with the R&TTE Directive [1999/5/EC], the EMC Directive [2004/108/EC], and the Low Voltage Directive [2006/95/EC] issued by the Commission of the European Community.

**CE RF Exposure Compliance**  
This device meets the EU requirements [1999/5/EC] and the International Commission on Non-Ionizing Radiation Protection (ICNIRP) on the limitation of exposure of the general public to electromagnetic fields by way of health protection.

**CEC Appliance Efficiency Compliance**  
The BC logo (shown at the left) indicates that this product complies with the California Energy Commission (CEC) energy efficiency standards for battery charger systems, set forth at California Code of Regulations Title 20, Sections 1601 through 1608.

**Disposal of Old Electrical & Electronic Equipment**  
This symbol on the product or on its packaging indicates that this product should not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste

handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office or your household waste disposal service.

**FRANÇAIS**

INSTRUCTIONS

Pour des instructions d'utilisation détaillées, rendez-vous sur <http://grainaudio.com/pages/user-guides>

ENREGISTREMENT

Nous vous remercions pour l'acquisition de ce produit Grain Audio. Que vous allez tout simplement adorer. Veuillez prendre quelques minutes et vous rendre sur [www.GrainAudio.com](http://www.GrainAudio.com) pour procéder à son enregistrement.

**BC CEC Appliance Efficiency Compliance**  
The BC logo (shown at the left) indicates that this product complies with the California Energy Commission (CEC) energy efficiency standards for battery charger systems, set forth at California Code of Regulations Title 20, Sections 1601 through 1608.

**Disposal of Old Electrical & Electronic Equipment**  
This symbol on the product or on its packaging indicates that this product should not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC NOTICE:** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
1. This device may not cause harmful interference.  
2. This device must accept any interference received, including interference that may cause undesired operation.

**FCC CAUTION:** Any changes or modifications not expressly approved by the manufacturer of this device could void the user's authority to operate the equipment.

The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.

**RF EXPOSURE:** The equipment complies with FCC RF exposure limits set forth for an uncontrolled environment.

**The lightning flash with arrowhead,** is intended to alert the user to the presence of

uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

**CAUTION**  
To prevent the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside.

**The exclamation point within an equilateral triangle** is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**WARNING:** To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

**IMPORTANT SAFETY INSTRUCTIONS**  
1. Read these instructions.  
2. Keep these instructions.  
3. Heed all warnings.  
4. Follow all instructions.  
5. Do not use this apparatus near water. This apparatus shall not be exposed to dripping or splashing, and no objects filled with liquids such as vases, shall be placed on the apparatus.  
6. Clean only with dry cloth.  
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled on or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Do not install in an area which impedes the access to the power plug.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

ENGLISH

INSTRUCTIONS

For detailed instructions on how to use your product, please visit <http://grainaudio.com/pages/user-guides>

REGISTRATION

Thanks for purchasing this Grain Audio product — you're going to love it. Please take a few minutes to go to [www.GrainAudio.com](http://www.GrainAudio.com) and register.

Why register?

- **Warranty** – registering your product with us will extend your warranty from one year to two
- **Product Updates** – allows us to contact you with important product notifications
- **Confirmation of Ownership** – provides a record in case of product loss or theft
- **Improved Product Development** – helps us continue to design products that make you happy

BATTERY

This Grain Audio product contains a rechargeable lithium-ion battery. It should only be charged with the charger provided with this product. Should your battery need replacement within the warranty period, we've got you covered. Grain Audio provides a battery replacement and recycling service that you can access through our website. Please DO NOT attempt to open this product or replace the battery yourself; really, it's a bad idea. In fact, opening the product voids the limited warranty.

CARE AND FEEDING

This is a real, solid wood product. Wood is a great material for making audio products, its resonant qualities cannot be matched by man-made plastics or composites. Wood is also a beautiful material, and the natural color and grain variations inherent to the wood are part of this beauty.

Being made from a natural material there are a few precautions to take when using your Grain Audio product.

1. **Keep things dry.** Wood (and electronics by the way) don't like being wet or submerged in liquid... steam saunas aren't great places for them either. Please keep this in mind.
2. **Take care.** The wood housing of your Grain Audio product will take some bumps and bruises. Unlike harder plastics these scrapes may show but that's okay; these will not affect the sound quality of your product. Plus, it'll make you look cool.
3. **Shade.** Wood will change color over time. This is a result of the natural interaction between the wood, oxygen and sunlight. We're pretty sure you can't control the aging content in the air around your Grain Audio product but you can keep it out of prolonged exposure to direct sunlight. No sunscreen though, that would be bad.
4. **Finish.** The wood in your Grain Audio product is protected by a durable water resistant finish. It is designed to last the life of the product and should not need refinishing. However, an occasional cleaning with a soft cloth will help keep things pretty.

LIMITED WARRANTY

**What Does The Warranty Cover?:** Grain Audio warrants that its products shall be free from defects in materials or workmanship, with the exceptions stated below.

**What Is The Period Of Coverage?:** This warranty runs for one year from the date of purchase, two if you register your product on [www.GrainAudio.com](http://www.GrainAudio.com). The term of any warranties implied by law shall expire when your limited warranty expires. Some states and/or Member States in the European Union do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

1. **Keep things dry.** Wood (and electronics by the way) don't like being wet or submerged in liquid... steam saunas aren't great places for them either. Please keep this in mind.
2. **Take care.** The wood housing of your Grain Audio product will take some bumps and bruises. Unlike harder plastics these scrapes may show but that's okay; these will not affect the sound quality of your product. Plus, it'll make you look cool.
3. **Shade.** Wood will change color over time. This is a result of the natural interaction between the wood, oxygen and sunlight. We're pretty sure you can't control the aging content in the air around your Grain Audio product but you can keep it out of prolonged exposure to direct sunlight. No sunscreen though, that would be bad.
4. **Finish.** The wood in your Grain Audio product is protected by a durable water resistant finish. It is designed to last the life of the product and should not need refinishing. However, an occasional cleaning with a soft cloth will help keep things pretty.

CUSTOMER SERVICE

The answers to most setup and performance questions can be found in the Troubleshooting guide. You can also consult the FAQs in the customer support section of our Web site at [www.GrainAudio.com](http://www.GrainAudio.com).

If you live in North America and still can't find the information you need, please contact our customer service team via email below or the Contact