




MUTE




OVERDUB




START





RUN



MAGIC




SUB LOOP




0 - I - II




SPEED



SLEW



CHANGE
LOOP LE NGTH



SLOW - 0 - FAST



I




DIRECTION




BKWD - FWD


PAN




MIX




PAN



MIX




MODE



I
II
III

BASINSKI




II
I
0

SELECT




II


POWER 2.1/5.5 15-24VDC CPP



HEADPHONES



LINE



ADDITIONAL OUT



I



II



III



IV

OUTPUT




INPUT




EXPANDER


LPF




FAIRY DUST




W/F




MU



SIGMA



P



I



0 - I - II




I



0 - I - II



VOLUME IN



FEEDBACK

