






MUTE




OVERDUB



START






RUN



MAGIC




SUB LOOP




0 - I - II




SLEW



SPEED




FEEDBACK




SCRUB




CHANGE
LOOP LENGTH




INPUT




PAN




MIX




PAN




VOLUME




MODE




BASINSKI




SELECT




POWER 2.1/5.5 15-24VDC CPP



HEADPHONES



LINE



ADDITIONAL OUT



OUTPUT




INPUT




FOOTSWITCH




LPF




FAIRY DUST




W/F




MU



SIGMA



P



VOLUME
IN



VOLUME
LOOP

