



NOTE: When MEM\_EXT is HIGH, the onboard memory is disabled. Otherwise, this pin shall stay floating.

PARENT INT. SEL.  
Selecting INT\_0 (J1-2) as the parent (SELF) means that the current IO device is the first device of the daisy chain.

Copyright (c) 2018 by J.P. Gravel, P. eng.  
jeanphilippe.gravel@gmail.com

Sheet: /		
File: ZMini.sch		
Title: RetroZ SBC For S80		
Size: USLedger	Date: 2018-12-26	Rev: 1
KiCad E.D.A. kicad (5.0.1)-4		Id: 1/1