

| Reference | Value | Footprint | Buy |
|-----------|----------------|-------------------------------|-------------------------|
| C1 | 22p | 0603 | Reichelt/DigiKey/Mouser |
| C10 | 100n | 0805 | Reichelt/DigiKey/Mouser |
| C11 | 100n | 0805 | Reichelt/DigiKey/Mouser |
| C12 | 100n | 0805 | Reichelt/DigiKey/Mouser |
| C2 | 100u | Elko 11x5mm RM2.5 | Reichelt/DigiKey/Mouser |
| C3 | 100n | 0805 | Reichelt/DigiKey/Mouser |
| C4 | 100n | 0805 | Reichelt/DigiKey/Mouser |
| C5 | 22p | 0603 | Reichelt/DigiKey/Mouser |
| C6 | 100n | 0805 | Reichelt/DigiKey/Mouser |
| C7 | 220u | Elko 11x5mm RM2.5 | Reichelt/DigiKey/Mouser |
| C8 | 100n | 0805 | Reichelt/DigiKey/Mouser |
| C9 | 100n | 0805 | Reichelt/DigiKey/Mouser |
| D1 | D_Schottky | RM10 | Reichelt/DigiKey/Mouser |
| D2 | D_Schottky | RM10 | Reichelt/DigiKey/Mouser |
| JP1 | JUMPER3 | 1x03 RM2,54 Jumper | Reichelt/DigiKey/Mouser |
| JP2 | JUMPER3 | 1x03 RM2,54 Jumper | Reichelt/DigiKey/Mouser |
| L1 | 680u | Elko 11.2x6.3mm RM2.5 | DigiKey/Mouser |
| P1 | CONN_01X02 | AKL RM5 | Reichelt/DigiKey/Mouser |
| P2 | FDSP_Header | Socket Strip 2x11 | Reichelt/DigiKey/Mouser |
| P3 | StdConn_ClkOut | 2x08 RM2,54 Wanne | Reichelt/DigiKey/Mouser |
| P4 | StsConn_ClkOut | 2x08 RM2,54 Wanne | Reichelt/DigiKey/Mouser |
| P5 | StdConn_ClkVar | 2x08 RM2,54 Wanne | Reichelt/DigiKey/Mouser |
| P6 | StdConn_ClkIn | 2x08 RM2,54 Wanne | Reichelt/DigiKey/Mouser |
| R1 | 2M2 | 0805 | Reichelt/DigiKey/Mouser |
| R2 | 100 | 0805 | Reichelt/DigiKey/Mouser |
| R3 | 3k3 | 0805 | Reichelt/DigiKey/Mouser |
| R4 | 2k | 0805 | Reichelt/DigiKey/Mouser |
| U1 | 74HCU14 | SOIC-14 3.9x8.7mm Pitch1.27mm | DigiKey/Mouser |
| U2 | LM2574 | DIP-8 | Reichelt/DigiKey/Mouser |
| Y1 | 12.288MHz | HC49 | Reichelt/DigiKey/Mouser |