


ROYSTON

Coffee table

130 x 58 x 30 cm





241123

ROYS-CT-SS14-A



habitat 

Components



Assembly Instructions

Please keep safe for future reference



Before assembling the furniture please identify all component parts.

It would be sensible to assemble the furniture as close to its final position as possible.


Do not place furniture directly in front of radiators, fires or any source of heat. Ensure the surface on which you are assembling the furniture is flat and clear of anything that might scratch it.

Check all packaging carefully for components and fittings before discarding it.




1



2



3



Care Instructions

Cleaning of Solid Timber / Veneers and Lacquered Surfaces

Any spillage should be removed immediately by using a damp cloth, then wiping dry the surface with a clean duster.

Repeat this procedure for periodic cleaning.

The use of furniture polishes or sprays is not necessary or recommended.

If for any reason you should have problems with your Habitat product please contact the store from which you purchased your product.

If you have any comments or suggestions regarding this product, assembly instructions or service received, please enquire at your nearest store or contact us on our website at :-

www.habitat.co.uk

Or write to us at :-

Habitat Retail Ltd. 489 - 499 Avebury Boulevard, Milton Keynes MK9 2NW

