

Field	description
wifiSignal	

### 3.3.26 GetPush

- Interface Description

It is used to get configuration of Push.

- Interface call instructions

Request URL	http://IPC_IP/api.cgi?cmd=GetPush&token=TOKEN
-------------	---

- POST Data

Data example
<pre>[   {     "cmd":"GetPush",     "action":1   } ]</pre>
Field description