






USB-A Socket
Connect To LBE-1420



RP2040 Zero



LBE-1420 Programmer