


How to Flash the firmware into the R36Max

1. Install the flash tools and Usb driver.....	2
1.1 Install the usb driver.....	2
2. Double click the RKDevTool.exe.....	2
3. Loading the firmware u need.....	3
4. Identify the loader device.....	3
5. Flash the firmware.....	4






1.Install the flash tools and Usb driver

 RKDevTool_Release.zip	2025/1/21 16:17
 DriverAssitant_v5.12.zip	2023/12/16 10:42


1.1 Install the usb driver



2. Double click the RKDevTool.exe

 rk3588-config.cfg	2023/12/16 10:42	文本文档
 rk3588-config.cfg	2023/12/16 10:42	文本文档
 RKDevTool.exe	2023/12/16 10:42	应用程序
 RKDevTool_manual_v1.2_cn.pdf	2023/12/16 10:42	WPS PDF 文档
 RKDevTool_manual_v1.2_en.pdf	2023/12/16 10:42	WPS PDF 文档

3. Loading the firmware u need



4. Identify the loader device

Use a data cable to connect one end to the computer and the other end to the device's OTG port.

Method 1: While the device is powered off, hold down the volume up button and then press and hold the power button.

Method 2: While the device is powered on, hold down the volume up button and then briefly press the reset (RST) button.

5. Flash the firmware

After identifying the MaskROM/Loader device, click "Upgrade," and the right side will prompt you that once the download is complete, the device will automatically restart and boot into the system interface.