



Arduino Uno: SCK=13 MOSI=11
Arduino Leonardo: no spi
Arduino Mega: no spi
Arduino M0 pro: SCK=13 MOSI=11
Arduino Zero: SCK=13 MOSI=11

place R15..17 if hardware SPI not possible
use software SPI
place R22 and R23 to use SPI header

This documentation describes Open Hardware and is licensed under the CERN OHL v. 1.2.
You may redistribute and modify this documentation under the terms of the CERN OHL v.1.2. (<https://ohw.org/cernohl>).
This documentation is distributed WITHOUT ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING OF MERCHANTABILITY, SATISFACTORY
QUALITY AND FITNESS FOR A PARTICULAR PURPOSE. Please see the CERN OHL v.1.2 for applicable conditions

generationmake

Sheet: /
File: ArduinoHMIShield.sch
Title: ArduinoHMI Shield

Size: A4
Date: 2019-08-23
KiCad E.D.A. kicad 5.0.2-bee/6a070ubuntu18.04.1

Rev: 1.2
Id: 1/1