

D1 can be replaced with any red LED and green LED  
SW1 is only needed if you want the device to remember more than 1 code.

