

DevEBox UAVX Pin Assignments

Pins Left->Right		QuadX
PE14	Beeper	
PE13	Landing Sw	
PE11	Aux1	
PE9	WP Nav Enable Sw / Probe	
PB9	K1	Front Left
PB8	K2	Left Rear
PB7	K3	Front Right
PB6	K4	Right Back
PC6	K5	Gimbal Roll
PC7	K6	Gimbal Pitch
PB0	Arming Sw	
Inverter to PD6	Sbus Rx (inverter on board)	
PC0	Rangefinder (analog)	