


# Config State



(A)

LCD: Can't configure AP  
LOG: Can't configure AP

(A)

- Network interface not found.
- Network interface down.
- Network interface cant be configured.

(B)

LCD: Can't setup web  
LOG: Can't setup web

(B)

- Cant find files.
- Permission denied.

(C)

LCD: Config invalid  
LOG: Config invalid

(C)

- Cant connect to essid.
- Form uncomplete.
- Essid not found.