

MASTER

Thank You Markquart Motors for your Support

Chippewa Valley Antique Engine and Model Club, Inc

2021 TRACTOR PULL CLASSES

2600 lb Classic Through 1959	5000 lb Classic Through 1959	7500 lb Farm Through 1975
3000 lb Classic Through 1959	5000 lb Open Through 1959	8500 lb Classic Through 1959
3200 lb Antique Through 1939	5600 lb Antique Through 1939	8500 lb Farm Through 1975
3200 lb Classic Through 1959	5600 lb Classic Through 1959	9500 lb Open Through 1959
3600 lb Antique Through 1939	5600 lb Farm Through 1975	9500 lb Farm Through 1975
3600 lb Classic Through 1959	6000 lb Classic Through 1959	10500 lb Farm Through 1975
4000 lb Antique Through 1939	6000 lb Farm Through 1975	11500 lb Farm Through 1975
4000 lb Classic Through 1959	6000 lb Open Through 1959	12500 lb Farm Through 1975
4000 lb Open Through 1959	6600 lb Classic Through 1959	LAST EVENT
4600 lb Antique Through 1939	6600 lb Farm Through 1975	Twin Pull : 5 mph
4600 lb Classic Through 1959	7000 lb Classic Through 1959	6000 lb Twin Pull
4600 lb Open Through 1959	7000 lb Farm Through 1975	9000 lb Twin Pull
5000 lb Antique Through 1939	7500 lb Classic Through 1959	12000 lb Twin Pull

2021 TRACTOR PULL RULES

1. Drivers must be 16 years of age or older with a valid driver license. Drivers 14 & 15 years of age can pull with proof of completion of a Tractor Safety Course and a copy of the certificate.
2. SPEED LIMIT ANTIQUE AND CLASSIC TRACTORS 5 MPH FARM CLASSES 8 MPH NO SPEED LIMIT ON OPEN CLASSES TWIN PULL SPEED LIMIT 5 MPH (NO DRINKING OF ALCOHOL) IF PULLING.
3. Antique tractors must be 1939 or older. Any tractor in question as being 1939 or older must have the serial number in the proper place and must be read easily. Tractors must have stock blocks, stock carbs. and no external parts manufactured for Tractor that has a serial number or parts to make a newer tractor appear legal will be disqualified. Classic Tractors Through 1959 Farm tractors through 1975. Pullers can register any time before their class starts.
4. Antique tractors can pull in the classic farm and open classes if they choose. But classic Farm and Open class tractors CANNOT pull in the Antique class. Tractors that are modified with aftermarket accessories (Over sized tires, etc) must pull in open classes. Turbo 's Allowed in Farm class and open
5. All tractors must weigh in before pulling (Allowed 100 lbs over for each class) Includes driver. Scale will be open 2 hours before pulls begins. No parts can be removed from tractor to make weight class tires hood etc
6. Antique and Classic classes rigid draw bar must not exceed 20 inches in height, not be closer than 18 inches from the center of the rear axle. Every puller must have a clevis or an eye hook.
7. Extra weights must not exceed beyond 36 inches behind the center of the rear axle. Weights must not interfere with the hook-up. Your tractor must have weight brackets, no weights are allowed on drivers platform or seat extra weights must be securely fastened..
8. Front weight bracket & weights CAN NOT exceed more than 11 feet from center rear axle.
9. 1st puller in each class does not have the option to re-pull. Puller can stop to adjust weights 1st 50ft
10. Antique and classic Tractors 5000 lb. and under are limited to a 15.5-38 maximum tire size. Tractors above 5000 Lbs are limited to 18.4-38 maximum tire size. NO cut tires or radials in antique or classic classes. Cut tires or radials will be allowed in Open and Farm classes No limit on tire size on Farm or Open classes. No locking or welded rear ends..

11. Limited to 4 pulls per tractor -3 classes, plus 1 open class if puller chooses. 2 DIFFERENT PULLERS CAN PULL IN SAME CLASS (SAME TRACTOR) (2 CLASSES ONLY)
12. Tractors must be operated in a safe manner at all time s. A pace tractor can be used (except in the open and Farm class) If the judges choose, otherwise the speed will be controlled by the flagman or person operating the eliminator. Horn will sound if you are exceeding the speed limit. 2nd horn sounded the puller is disqualified. Any tractor puller violating the track boundary will be flagged and measured.
13. While pulling, the driver must remain on the seat with one hand on the steering wheel, no jumping or bouncing will be allowed, however, leaning will be all owed .
14. Tractors must stop immediately upon red flag signal from flagman, or be disqualified. If the track judge stops a puller for any reason the puller takes that distance. Any weights fall off before the pin is pulled the tractor will be measured at that point.
15. Torque amplifiers can be shifted once during pull.
16. Tractor puller will be flagged, if the front end raises higher, than the track judge decides is safe.)
17. Tractors must be wheel driven, no crawlers or dual wheels.
18. Original steel wheels will be allowed to pull where allowed. Steel wheels shall pull last in each class. One set of original extension rims will be allowed. Front wheel assist cannot be used while pulling
19. Anyone caught tampering with another puller's tractor will be disqualified from pulling . No drinking while pulling. If disqualification is ruled on top place Tractor, all other tractors move up one place .
- 20 .The sponsoring organization must provide a method to unload & load tractors on the grounds.
- 21 The decision of the Track Judges and Officers will be final on areas of dispute not covered in these rules.

FOR FUTHER INFORMATION CONTACT: DARYL DEHNKE Home: 715-832-3977 or 715-559-5597 Cell

EMAIL: johndeere3641@att.net