

**layout: FAQ title: Configuration Settings are  
Resetting on Power Up date: '2018-11-08 14:25'  
Author: Gabriel Isko**

---

## **Q: My device's configuration settings are not being saved after a power cycle or Reboot**

---

Configuration settings must be saved to flash manually when they are changed.

## **Steps to Save configuration settings to Flash Memory**

---

- If you are editing your configuration settings from the Run Tab of Roborun+, please make sure you save your settings to the controller:
- If you are configuring your settings from serial commands, or a MicroBasic script you will have to save them to flash using the `!EES` runtime command. This can be done from the console tab of Roborun+:
- You can also invoke `!EES` from your MicroBasic script:

```
setcommand(_EES, 1 )
```

## **Further Questions**

---

Please reference the `!EES` documentation in **SECTION 19: Command Reference** of our [User Manual](#). If you still have questions please email [techsupport@roboteq.com](mailto:techsupport@roboteq.com).