

# Quartus II Installation Guide

Link down phần mềm

<https://www.intel.com/content/www/us/en/software-kit/666221/intel-quartus-ii-web-edition-design-software-version-13-1-for-windows.html>

## Downloads

Multiple Download

Individual Files

DVD Files

Additional Software

Updates

## Multiple Download

Intel® Quartus® II Web Edition Software (Device support included)

Download  
Quartus-web-13.1.0.162-windows.tar

Size: 4.4 GB

SHA1: c360f10b89aa5ee4c7bb11a1c6c8b1195a5c41ac


[What's Included?](#)

### Download and install instructions:


1. Download the software .tar file and the appropriate device support files.
2. Extract the files into the same temporary directory.
3. Run the setup.bat file.

[Read Intel® FPGA Software Installation FAQ](#)

Giải nén file .tar download về bằng phần mềm Winrar hoặc 7zip.




Vào folder vừa giải nén được, chạy file setup.bat.




Đợi 1 chút để loading file cài đặt.

Hộp thoại cài đặt hiện ra. Bấm Next.




Tích vào I accept the agreement và chọn Next.




Chọn folder cài đặt và ấn Next.

Lưu ý: Ổ cứng dùng để cài đặt Quartus II yêu cầu cần ít nhất 15G dung lượng trống.




Chọn phần mềm biên dịch, thiết bị và phần mềm mô phỏng như hình dưới, sau đó chọn Next.


Lưu ý: Devices chọn dòng chip Cyclone IV và V.




Chọn Next.



Chờ đợi việc cài đặt hoàn thành.



## Hoàn thành cài đặt



## Giao diện của chương trình

