

General Podium Instructions

To use the projector, follow these steps:

1. Press the power ON button. You should hear a beep
2. If you need to switch to a different source, use the following buttons
 - a. DVD or VCR = VIDEO (on remote)
 - b. Podium Computer = Computer 1 (on remote)
 - c. Instructor Laptop = Computer 2 (on remote)
3. To use your laptop, you may need to use your function keys (usually Fn + F8)
 - a. If you have an NVIDIA Graphics card, you may need further assistance
4. Volume Control for each device is on the bottom left of the remote

Volume Control

Power buttons

remote

Input selection:
VIDEO
COMPUTER 1
COMPUTER 2

Please shut down projector at end of class

5. To turn off projector, press the power OFF button
 - a. You will need to press once again to confirm

For help please call 773-442-5060 or xt. 5060