

# **Data Extract From PI AF Elements And Attributes**

This application allows you to extract the attributes data into text file. The text file can be uploaded into PI DA for new recording of PI Points.

## **How It Works**

1. Select The Elements From Tree Views
2. Choose The Attributes From The Elements
3. Specify the Timestamp: Start and End Time
4. Select The Archive Type you want to extract.
5. Type Get Data Button which will extract data from PI and generate TEXT files.
6. The generated file will have the architectures as name and content as values.

For more information, please feel free to contact: Sunlead Technology Inc.