


STM32 Cube MX software

In this document, We are showing how to install the STM32CubeMx on a Windows PC.

Step 1: Download STM32CubeMx from [here](#).



We have to choose the software (*Get Software*) according to our machine.

Part Number	General Description	Latest version	Download	All versions
+ STM32CubeMX-Lin	STM32Cube init code generator for Linux	6.5.0	Get latest	Select version
+ STM32CubeMX-Mac	STM32Cube init code generator for macOS	6.5.0	Get latest	Select version
+ STM32CubeMX-Win	STM32Cube init code generator for Windows	6.5.0	Get latest	Select version

Step 2 : Accept license in the next page.



License Agreement



Please indicate your acceptance or NON-acceptance by selecting "I ACCEPT" or "I DO NOT ACCEPT" as indicated below in the media.

BY INSTALLING COPYING, DOWNLOADING, ACCESSING OR OTHERWISE USING THIS SOFTWARE PACKAGE OR ANY PART THEREOF (AND THE RELATED DOCUMENTATION) FROM STMICROELECTRONICS INTERNATIONAL N.V, SWISS BRANCH AND/OR ITS AFFILIATED COMPANIES (STMICROELECTRONICS), THE RECIPIENT, ON BEHALF OF HIMSELF OR HERSELF, OR ON BEHALF OF ANY ENTITY BY WHICH SUCH RECIPIENT IS EMPLOYED AND/OR ENGAGED AGREES TO BE BOUND BY THIS SOFTWARE PACKAGE LICENSE AGREEMENT.

Under STMicroelectronics' intellectual property rights and subject to applicable licensing terms for any third-party software incorporated in this software package and applicable Open Source Terms (as defined here below), the redistribution, reproduction and use in source and binary forms of the software package or any part thereof, with or without modification, are permitted provided that the following conditions are met:

1. Redistribution of source code (modified or not) must retain any copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form, except as embedded into microcontroller or microprocessor device manufactured by or for STMicroelectronics or a software update for such device, must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of STMicroelectronics nor the names of other contributors to this software package may be used to endorse or promote products derived from this software package or part thereof without specific written permission.
4. This software package or any part thereof, including modifications and/or derivative works of this software package, must be used and execute solely and exclusively on or in combination with a microcontroller or a microprocessor devices manufactured by or for STMicroelectronics.

Step 3 : In the next page enter the details like first name, second name and email address. Mark the privacy statement and then click download.



Get Software

If you have an account on my.st.com, login and download the software without any further validation steps.

Login/Register

If you don't want to login now, you can download the software by simply providing your name and e-mail address in the form below and validating it.

This allows us to stay in contact and inform you about updates of this software.

For subsequent downloads this step will not be required for most of our software.

First Name:

Last Name:

E-mail address:

Please review our [Privacy Statement](#) that describes how we process your profile information and how to assert your personal data protection rights

☐ Please keep me informed about future updates for this software or new software in the same category

Download

Step 4: Then the verification link is sent to an email and click the link in order to download the software.



Start your software download

Hi Harrin

Please click on this button to validate your email address and start the download of the requested software:


Download now

If you have any further issues, please send your request to our [online support](#) using the subject line: Software download issues.


Thank you,

STMicroelectronics
www.st.com


Step 5 : After we download the software click to open file.





Step 6: A Dialog box appears on the screen asking "Do you want to allow changes in your device , click yes"". Then the software automatically starts extracting.




Step 7: Click Next as shown in the below pic.







Step 8: Click next as shown in the below picture.



Step 9: click Next as shown in the below picture.





Step 10: Press Done and the software is installed on the computer.

STM32CubeMX Installation done

MX



Installation has completed successfully.

An uninstaller program has been created in:

C:\Program Files\STMicroelectronics\STM32Cube\STM32CubeMX\Uninstaller



Generate an automatic installation script

STMicroelectronics



Done