



Installation Guide

Guest Tables WT804GT



Parts

Standard Table Parts

- | Qty | Part |
|-----|-------------------------|
| 4 | 60-7 Flanges |
| 6 | 30-6 Single Socket Tees |
| 4 | External Leg Pipes |
| 4 | Internal Leg Pipes |
| 2 | Depth Pipes |
| 1 | Width Pipe |

Tools

- Allen Key (Included)
- Hammer (for plugs)
- Screw Driver
- Level

Basic Installation Instructions

1. Confirm that you have all the required parts.
2. Assemble the parts according to the enclosed diagram.
3. When you initially assemble the unit loosely tighten the fitting set screws. After the unit is completely assembled, fully tighten all set screws.
4. If installing plugs, place cloth over plug and hammer into place.