


See user setup.h in TFT_eSPI library
for pin assignments

note wrover and huzzah versions



backVIEW – vcc bottom

this is screen back -- not front